magicolor® 5450 Reference Guide

4138-7764-04A
1800764-001D

Copyright Notice

The digitally encoded software and publication included with your printer are Copyrighted © 2005 by KONICA MINOLTA BUSINESS TECHNOLOGIES, INC., Marunouchi Center Building, 1-6-1 Marunouchi, Chiyoda-ku, Tokyo, 100-0005, Japan. All Rights Reserved.

This software may not be reproduced, modified, displayed, transferred, or copied in any form or in any manner or on any media, in whole or in part, without the express written permission of KONICA MINOLTA PRINTING SOLUTIONS U.S.A., INC.
No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of KONICA MINOLTA. The information contained in this guide is intended for use with the KONICA MINOLTA magicolor 5450 printers only.

About the GPL (General Public License)

This driver is written for Linux, which is written and distributed under the GNU GPL. The printing system CUPS adopted to run on the Linux is published by ESP (Easy Software Products) under the GPL. All source codes that we write must be available to the general public.

Trademarks

KONICA MINOLTA, the KONICA MINOLTA logo, and PageScope are trademarks or registered trademarks of KONICA MINOLTA HOLDINGS, INC.

magicolor is a trademark or registered trademark of KONICA MINOLTA PRINTING SOLUTIONS U.S.A., INC.

All other trademarks and registered trademarks are the property of their respective owners.

Notice

KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. reserves the right to make changes to this guide and to the equipment described herein without notice. Considerable effort has been made to ensure that this manual is free of inaccuracies and omissions. However, KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. makes no warranty of any kind including, but not limited to, any implied warranties of merchantability and fitness for a particular purpose with regard to this manual. KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. assumes no responsibility for, or liability for, errors contained in this manual or for incidental, special, or consequential damages arising out of the furnishing of this manual, or the use of this manual in operating the equipment, or in connection with the performance of the equipment when so operated.

SOFTWARE LICENSE AGREEMENT

This package contains the following materials provided by Konica Minolta Business Technologies, Inc. (KMBT): software included as part of the printing system, the digitally-encoded machine-readable outline data encoded in the special format and in the encrypted form (“Font Programs”), other software which runs on a computer system for use in conjunction with the Printing Software (“Host Software”), and related explanatory written materials (“Documentation”). The term “Software” shall be used to describe Printing Software, Font Programs and/or Host Software and also include any upgrades, modified versions, additions, and copies of the Software.

The Software is being licensed to you under the terms of this Agreement.

KMBT grants to you a non-exclusive sublicense to use the Software and Documentation, provided that you agree to the following:

1. You may use the Printing Software and accompanying Font Programs for imaging to the licensed output device(s), solely for your own internal business purposes.
2. In addition to the license for Font Programs set forth in Section 1 (“Printing Software”) above, you may use Roman Font Programs to reproduce weights, styles, and versions of letters, numerals, characters and symbols (“Typefaces”) on the display or monitor for your own internal business purposes.
3. You may make one backup copy of the Host Software, provided your backup copy is not installed or used on any computer. Notwithstanding the above restrictions, you may install the Host Software on any number of computers solely for use with one or more printing systems running the Printing Software.
4. You may assign its rights under this Agreement to an assignee of all of Licensee’s right and interest to such Software and Documentation (“Assignee”) provided you transfer to Assignee all copies of such Software and Documentation Assignee agrees to be bound by all of the terms and conditions of this Agreement.
5. You agree not to modify, adapt or translate the Software and Documentation.
6. You agree that you will not attempt to alter, disassemble, decrypt, reverse engineer or decompile the Software.
7. Title to and ownership of the Software and Documentation and any reproductions thereof shall remain with KMBT.
8. Trademarks shall be used in accordance with accepted trademark practice, including identification of the trademark owner’s name. Trademarks can only be used to identify printed output produced by the Software. Such use of any trademark does not give you any rights of ownership in that trademark.
9. You may not rent, lease, sublicense, lend or transfer versions or copies of the Software that the Licensee does not use, or Software contained on any unused media, except as part of the permanent transfer of all Software and Documentation as described above.
10. In no event will KMBT or its licensor be liable to you for any consequential, incidental INDIRECT, PUNITIVE or special damages, including any lost profits or lost saving, even if KMBT has been advised of the possibility of such damages, or for any claim by any third party. KMBT or its licensor disclaims all warranties with regard to the software, express or implied, including, without limitation implied warranties of merchantability, fitness for a particular purpose, title and non-infringement of third party rights. Some states or jurisdictions do not allow the exclusion or limitation of incidental, consequential or special damages, so the above limitations may not apply to you.

11. Notice to Government End Users: The Software is a “commercial item,” as that term is defined at 48 C.F.R.2.101, consisting of “commercial computer software” and “commercial computer software documentation,” as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4, all U.S. Government End Users acquire the Software with only those rights set forth herein.
12. You agree that you will not export the Software in any form in violation of any applicable laws and regulations regarding export control of any countries.

About Adobe Color Profile

ADOBE SYSTEMS INCORPORATED
COLOR PROFILE LICENSE AGREEMENT

NOTICE TO USER: PLEASE READ THIS CONTRACT CAREFULLY. BY USING ALL OR ANY PORTION OF THE SOFTWARE YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS SOFTWARE YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE WITH THE TERMS OF THIS AGREEMENT, DO NOT USE THE SOFTWARE.

1. DEFINITIONS In this Agreement, “Adobe” means Adobe Systems Incorporated, a Delaware corporation, located at 345 Park Avenue, San Jose, California 95110. “Software” means the software and related items with which this Agreement is provided.
2. LICENSE Subject to the terms of this Agreement, Adobe hereby grants you the worldwide, non-exclusive, nontransferable, royalty-free license to use, reproduce and publicly display the Software. Adobe also grants you the rights to distribute the Software only (a) as embedded within digital image files and (b) on a standalone basis. No other distribution of the Software is allowed; including, without limitation, distribution of the Software when incorporated into or bundled with any application software. All individual profiles must be referenced by their ICC Profile description string. You may not modify the Software. Adobe is under no obligation to provide any support under this Agreement, including upgrades or future versions of the Software or other items. No title to the intellectual property in the Software is transferred to you under the terms of this Agreement. You do not acquire any rights to the Software except as expressly set forth in this Agreement.
3. DISTRIBUTION If you choose to distribute the Software, you do so with the understanding that you agree to defend, indemnify and hold harmless Adobe against any losses, damages or costs arising from any claims, lawsuits or other legal actions arising out of such distribution, including without limitation, your failure to comply with this Section 3. If you distribute the Software on a standalone basis, you will do so under the terms of this Agreement or your own license agreement which (a) complies with the terms and conditions of this Agreement; (b) effectively disclaims all warranties and conditions, express or implied, on behalf of Adobe; (c) effectively excludes all liability for damages on behalf of Adobe; (d) states that any provisions that differ from this Agreement are offered by you alone and not Adobe and (e) states that the Software is available from you or Adobe and informs licensees how to obtain it in a reasonable manner on or through a medium customarily used for software exchange. Any distributed Software will include the Adobe copyright notices as included in the Software provided to you by Adobe.

4. DISCLAIMER OF WARRANTY Adobe licenses the Software to you on an “AS IS” basis. Adobe makes no representation as to the adequacy of the Software for any particular purpose or to produce any particular result. Adobe shall not be liable for loss or damage arising out of this Agreement or from the distribution or use of the Software or any other materials. ADOBE AND ITS SUPPLIERS DO NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SOFTWARE, EXCEPT FOR ANY WARRANTY, CONDITION, REPRESENTATION OR TERM TO THE EXTENT TO WHICH THE SAME CANNOT OR MAY NOT BE EXCLUDED OR LIMITED BY LAW APPLICABLE TO YOU IN YOUR JURISDICTION, ADOBE AND ITS SUPPLIERS MAKE NO WARRANTIES, CONDITIONS, REPRESENTATIONS OR TERMS, EXPRESS OR IMPLIED, WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE AS TO ANY OTHER MATTERS, INCLUDING BUT NOT LIMITED TO NON-INFRINGEMENT OF THIRD PARTY RIGHTS, INTEGRATION, SATISFACTORY QUALITY OR FITNESS FOR ANY PARTICULAR PURPOSE. YOU MAY HAVE ADDITIONAL RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION. The provisions of Sections 4, 5 and 6 shall survive the termination of this Agreement, howsoever caused, but this shall not imply or create any continued right to use the Software after termination of this Agreement.
5. LIMITATION OF LIABILITY IN NO EVENT WILL ADOBE OR ITS SUPPLIERS BE LIABLE TO YOU FOR ANY DAMAGES, CLAIMS OR COSTS WHATSOEVER OR ANY CONSEQUENTIAL, INDIRECT, INCIDENTAL DAMAGES, OR ANY LOST PROFITS OR LOST SAVINGS, EVEN IF AN ADOBE REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSS, DAMAGES, CLAIMS OR COSTS OR FOR ANY CLAIM BY ANY THIRD PARTY. THE FOREGOING LIMITATIONS AND EXCLUSIONS APPLY TO THE EXTENT PERMITTED BY APPLICABLE LAW IN YOUR JURISDICTION. ADOBE’S AGGREGATE LIABILITY AND THAT OF ITS SUPPLIERS UNDER OR IN CONNECTION WITH THIS AGREEMENT SHALL BE LIMITED TO THE AMOUNT PAID FOR THE SOFTWARE. Nothing contained in this Agreement limits Adobe’s liability to you in the event of death or personal injury resulting from Adobe’s negligence or for the tort of deceit (fraud). Adobe is acting on behalf of its suppliers for the purpose of disclaiming, excluding and/or limiting obligations, warranties and liability as provided in this Agreement, but in no other respects and for no other purpose.
6. TRADEMARKS Adobe and the Adobe logo are the registered trademarks or trademarks of Adobe in the United States and other countries. With the exception of referential use, you will not use such trademarks or any other Adobe trademark or logo without separate prior written permission granted by Adobe.
7. TERM This Agreement is effective until terminated. Adobe has the right to terminate this Agreement immediately if you fail to comply with any term hereof. Upon any such termination, you must return to Adobe all full and partial copies of the Software in your possession or control.
8. GOVERNMENT REGULATIONS If any part of the Software is identified as an export controlled item under the United States Export Administration Act or any other export law, restriction or regulation (the “Export Laws”), you represent and warrant that you are not a citizen, or otherwise located within, an embargoed nation (including without limitation Iran, Iraq, Syria, Sudan, Libya, Cuba, North Korea, and Serbia) and that you are not otherwise prohibited under the Export Laws from receiving the Software. All rights to use the Software are granted on condition that such rights are forfeited if you fail to comply with the terms of this Agreement.

9. GOVERNING LAW This Agreement will be governed by and construed in accordance with the substantive laws in force in the State of California as such laws are applied to agreements entered into and to be performed entirely within California between California residents. This Agreement will not be governed by the conflict of law rules of any jurisdiction or the United Nations Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. All disputes arising out of, under or related to this Agreement will be brought exclusively in the state Santa Clara County, California, USA.
10. GENERAL You may not assign your rights or obligations granted under this Agreement without the prior written consent of Adobe. None of the provisions of this Agreement shall be deemed to have been waived by any act or acquiescence on the part of Adobe, its agents, or employees, but only by an instrument in writing signed by an authorized signatory of Adobe. When conflicting language exists between this Agreement and any other agreement included in the Software, the terms of such included agreement shall apply. If either you or Adobe employs attorneys to enforce any rights arising out of or relating to this Agreement, the prevailing party shall be entitled to recover reasonable attorneys' fees. You acknowledge that you have read this Agreement, understand it, and that it is the complete and exclusive statement of your agreement with Adobe which supersedes any prior agreement, oral or written, between Adobe and you with respect to the licensing to you of the Software. No variation of the terms of this Agreement will be enforceable against Adobe unless Adobe gives its express consent, in writing, signed by an authorized signatory of Adobe.

ICC Profile for TOYO INK Standard Color on Coated paper (TOYO Offset Coated 2.0)

This ICC Profile (TOYO Offset Coated 2.0) characterizes Japanese offset press on Coated paper and is fully compatible with ICC profile format.

About “TOYO INK Standard Color on Coated paper”

This is the standard for color reproduction of sheet-fed offset press on Coated paper made by TOYO INK MFG.CO., LTD. (“TOYO INK”).
This standard is made from printing test with using TOYO INK’s sheet-fed offset printing inks and TOYO INK’s own printing conditions.
“TOYO INK Standard Color on Coated paper” is compatible with “JAPAN COLOR”.

Agreement

1. The reproduction of images on a printer or a monitor using this ICC Profile do not completely match the TOYO INK Standard Color on Coated paper.
2. Any and all copyrights of this ICC Profile shall remain in TOYO INK; therefore you shall not transfer, provide, rent, distribute, disclose, or grant any rights in this ICC Profile to any third party without the prior written consent of TOYO INK.
3. In no event will TOYO INK its directors, officers, employees or agents be liable to you for any consequential or incidential, either direct or indirect, damages(including damages for loss of business profits, business interruption, loss of business information, and the like)arising out of the use or inability to use this ICC Profile.
4. TOYO INK shall not be responsible for answering any question related to this ICC Profile.

5. All company names and product names used in this document is the trademarks or registered trademarks of their respective holder.

This ICC Profile made by GretagMacbeth ProfileMaker and granted TOYO INK certain license to distribute by GretagMacbeth AG.

TOYO Offset Coated 2.0 © TOYO INK MFG. CO., LTD. 2004

OpenSSL Statement

OpenSSL License

Copyright (c) 1998-2003 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment:

   “This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.openssl.org/)”

4. The names “OpenSSL Toolkit” and “OpenSSL Project” must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
5. Products derived from this software may not be called “OpenSSL” nor may “OpenSSL” appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment:

   “This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl.org/)”

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT “AS IS” AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Original SSLeay License

Copyright (c) 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com). The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are aheared to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code.
The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:

   "This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)"

   The word 'cryptographic' can be left out if the rouines from the library being used are not cryptographic related :-).
4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement:

   "This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publically available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.]

Contents

1 Operation on Mac OS X 1
System Requirements for the Printer Driver 2
Installing the Printer Driver 3
Installing the magicolor 5450 Printer Driver 3
Printer Setup Utility Settings 8
When Using a USB Connection 8
When Using a Network Connection 11
AppleTalk Setting 11
IP Printing Setting 14
Specifying Port 9100 17
Selecting Print Options 20
Specifying Page Setup Settings 22
Page Attributes Options 23
Custom Paper Size Options 24
Summary 25
Specifying Print Settings 26
Print Dialog Box 27
Common buttons 28
Copies & Pages 29
Layout 30

Output Options 31
Scheduler 32
Paper Handling 33
ColorSync 34
Cover Page 34
Error Handling 35
Paper Feed 36
Color Options 37
Advanced Color Options/Image 38
Advanced Color Options/Text 39
Advanced Color Options/Graphics 40
Advanced Color Options/Simulation 41
Printer Features 42
Summary 42
Troubleshooting 43

2 Operation on Mac OS 9 45
System Requirements for the Printer Driver 46
Installing the Printer Driver 47
Selecting the Printer in the Chooser 48
Selecting the Printer in the Desktop Printer Utility 51
Specifying Page Setup Settings 54
Page Attributes Options 54
Specifying a Custom Paper Size 55
Specifying Print Settings 57
Print Dialog Box Options 58
Common buttons 59
General Options 60
Background Printing 61
Color Matching 62
Cover Page 63
Font Settings 64
Job Logging 65
Layout 66
Save as File 67
Watermark 68
Job Retention 69
Color Options 70
Advanced Options 1 71
Advanced Options 2 72
Printer Features 73
Checking Print Jobs 74
Troubleshooting 75

3 Operation on Linux 77
System Requirements for the Printer Driver 78
Installing PPD File From the Command Line 79
Adding the Printer 80
Specifying Printer Driver Settings 82
Displaying the Settings Page 82
Printer Driver Settings 83
Extra 83
General 83
Image Options 84
Options Installed 85
Simulation Profile 85
Text Options 86
Banners 86
Printing a Document 87
Example Using LPR Command 87
Example Using OpenOffice 88
Checking Print Jobs 91
Troubleshooting 92

4 Printer Management Utilities 93
Installing Printer Management Utilities on Windows 94

5 Understanding the Ethernet Configuration Menus 97
Ethernet Menu 98
Location within the Configuration Menu 98
Accessing the Ethernet Menu 99
Using the Network Menu Options 100
TCP/IP 100
TELNET 101
NetWare 102
AppleTalk 102
Speed/Duplex 102
CAMERA DIRECT 103

6 Network Printing 105
Network Connection 106
Theory 106
Making the Connection 107
Ethernet Interface 107
Using DHCP 107
Setting the Address Manually 109
Network Printing 113
Bonjour 113
BOOTP 113
DHCP 114

DDNS (Dynamic DNS) 114
HTTP 114
IPP 114
IPX/SPX 115
LPD/LPR 115
NetBEUI 115
SLP 115
SNMP 116
Port 9100 116
SMB 116
SMTP 116
Printing via IPP (Internet Printing Protocol) – Windows Server 2003/XP/2000 117
Adding an IPP Port using Add Printer Wizard 117
Troubleshooting 119

7 Using Crown Print Monitor+ 121
Adding a Crown Port After Installing Crown Print Monitor+ 122
For Windows XP, 2000 and NT 4.0: 122
For Windows Me and 98 SE: 123
Configure Crown Port+ 125

8 Using PageScope Web Connection 127
About PageScope Web Connection 128
Display Language 128
Requirements 128
Setting Up the Printer Web Page 130
Determining the Printer Name 130
Setting Up Your Browser Software 130
Internet Explorer (version 6.0 for Windows) 131
Netscape Navigator (version 7.1) 132
Understanding the PageScope Web Connection Window 133
Navigation 133
Current Status 134
User Mode 134
Administrator Mode 134
Viewing Printer Status 135
System Page 135
Summary (shown above) 136
Device Information 137
Detail 138
Counter 145
Online Assistance 146
Job Page 147
Active Job List (shown above) 147
Done Job List 148

Done Job List (Detail) 149
Print Page 150
Default Settings 150
Download Font/Form 159
Report Types 163
Direct Print 164
Configuring the Printer 165
System Page 165
Date/Time 165
Admin Password 167
Device Information 169
ROM Version 172
Online Assistance 173
Maintenance 175
Print 180
Local Interface 180
Default Settings 181
Download Font/Form 201
Network 205
TCP/IP 205
Bonjour 211
NetWare 212
FTP 219
SNMP 220
SMB 221
AppleTalk 222
Email 223
SSL/TLS Information 224
SSL/TLS Setting 225
Self-signed Certificate Setting 226
Request a certificate 228
Certificate Request 230
Install a Certificate 231
Encryption Strength Setting 232
Remove a Certificate 233
Mode using SSL/TLS 234
Log Accounting Page 235
Job (shown above) 235

1 Operation on Mac OS X

System Requirements for the Printer Driver

Before installing the printer driver, make sure that your system meets the following system requirements.

Computer	Apple Macintosh computer with a PowerPC G3 or later processor (PowerPC G4 or later is recommended)
Connecting the computer and printer	USB connection, network connection (10Base-T/100Base-TX/1000Base-T)
Operating system	Mac OS X 10.2 or later (We recommend installing the newest patch.) Mac OS X Server 10.2 or later
RAM	More than OS recommendation (128 MB or more is recommended)
Available disk space	256 MB or more (for storing images)

Installing the Printer Driver

You must have administrator privileges in order to install the printer driver.

Before proceeding with the installation, be sure to exit all running applications.

Installing the magicolor 5450 Printer Driver

The procedure for installing the printer driver on Mac OS X 10.3 is described below. The following procedure or some steps may be different depending on the version of the operating system being used. Complete the installation according to the instructions in the dialog boxes that appear.

1 Insert the magicolor 5450 Software Utilities CD-ROM in the CD/DVD drive of your Macintosh.

2 Double-click the CD icon on the desk top, drivers folder, mac folder, OSX folder, and then double click the **mc5450 OSX Installer.dmg** disk image-file.

The disk image mc5450 OSX Installer appears on the desktop.

3 *Double-click the mc5450 OSX Installer_103104.pkg package file in the disk image.*

The installer for the printer driver starts up.

4 Click **Continue**.



5 Click **Continue**.



6 Check the details of the license agreement, and then click **Continue**.


Install magicolor 5450
Software License Agreement
Introduction
Read Me
License
Select Destination
Installation Type
Installing
Finish Up
English
Program License Agreement
NOTICE TO USER. Please carefully read the License Agreement before using or copying this software package. The right to use this software product is conditional on your agreement on the following terms. Copying and using this software indicates that you have accepted these terms and conditions. If you do not agree to the terms of the License, you may return this software package along with the other components of this product to the place of purchase, and you will be reimbursed or credited according to the policy of the reseller or representative of KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. or its affiliate company (hereinafter collectively "KONICA MINOLTA") from whom you obtained this product. You assume responsibility for the selection of this product to achieve your intended results. Furthermore, you are responsible for installation, use, and results obtained from the product.
LICENSE AGREEMENT.
Print...
Save...
Go Back
Continue

7 Click **Agree** in the confirmation dialog box if you agree to the terms of the license.


To continue installing the software, you must agree to the terms of the software license agreement.
Click Agree to continue or click Disagree to cancel the installation.
Disagree
Agree

8 In the **Select a Destination** page, select the disk in which you wish to install the software, and then click **Continue**.



9 Click **Install** in the **Easy Install** page.



Installation starts.

10 Enter the administrator user name and password in the **Authenticate** dialog box, and then click **OK**.

11 After the installation has been completed, click **Close**.



This completes the installation of the magicolor 5450 printer driver.

Printer Setup Utility Settings

When Using a USB Connection

1. Use a USB cable to connect the printer to your computer.
2. Check that the printer is turned on, and then restart the computer.
3. Open **Printer Setup Utility**, which can be accessed by clicking Startup Disk, then **Applications**, then **Utilities**.
4. In the **Printer List**, click **Add**.



5. Select **USB** from the pop-up menu.



6 Select **magicolor5450** in the **Product** list.



*If **magicolor5450** does not appear, check that the printer is turned on and the USB cable is connected, and then restart the computer.*

7 Select **KONICA MINOLTA** from the **Printer Model** pop-up menu.

8 Select **KONICA MINOLTA mc5450 PPD** from **Model Name** list.



9 Click **Add**.

*The new printer appears in the **Printer List** screen.*



When Using a Network Connection

The network connection settings can be specified in one of three ways: AppleTalk setting, IP printing setting and Specifying Port 9100.

AppleTalk Setting

1 Connect the printer to an Ethernet network.

2 Open **Printer Setup Utility**, which can be accessed by clicking Startup Disk, then **Applications**, then **Utilities**.

3 Click Add in the **Printer List**.



4 Select **AppleTalk** from the pop-up menu.



The AppleTalk screen appears.

5 Select **magicolor5450** from the **Name** list.



6 Select **KONICA MINOLTA** from the **Printer Model** pop-up list.



7 Click **Add**.



The new printer appears in the Printer List screen.

IP Printing Setting

1 Connect the printer to an Ethernet network.

2 Open **Printer Setup Utility**, which can be accessed by clicking Startup Disk, then **Applications**, then **Utilities**.

3 Click **Add** in the **Printer List**.



4 Select **IP Printing** from the pop-up menu.



The IP Printing screen appears.



5 Select **LPD/LPR** from the **Printer Type** pop-up menu.

6 Enter the IP address for the printer in the **Printer Address** text box.

7 Enter “lp” in the **Queue Name** text box.



8 Select **KONICA MINOLTA** from the **Printer Model** pop-up menu.

9 Select **KONICA MINOLTA mc5450 PPD** in the **Model Name** list.



10 Click **Add**.

*The new printer appears in the **Printer List** screen.*

Specifying Port 9100

1 Connect the printer to an Ethernet network.

2 Open **Printer Setup Utility**, which can be accessed by clicking Startup Disk, then **Applications**, then **Utilities**.

3 In the **Printer List**, click **Add** while pressing the Option key.



4 Select **Advanced** from the pop-up menu.



*The **Advanced** screen appears.*



5 Select **AppSocket/HP JetDirect** from the **Device** pop-up menu.

6 Enter the name for the printer in the **Device Name** text box.

7 In the **Device URI** text box, enter “socket://” followed by the IP address for the printer.

8 Select **KONICA MINOLTA** from the **Printer Model** pop-up menu.

9 Select **KONICA MINOLTA mc5450 PPD** in the **Name** list.



10 Click **Add**.

*The new printer appears in the **Printer List** screen.*

Selecting Print Options

1 Open **Printer Setup Utility**, which can be accessed by clicking Startup Disk, then **Applications**, then **Utilities**.

2 Select this printer in the **Printer List**, and then select **Show Info** from the **Printers** menu.



3 Select **Installable Options** from the pop-up menu.



4 Select the appropriate settings in the **Printer Memory**, **Hard Disk**, **Paper Source Unit** and **Duplex Unit** pop-up menus according to your printer setup, and then click **Apply Changes**.



5 Close the **Printer Info** dialog box.

Specifying Page Setup Settings

The following dialog box appears when **Page Setup...** is selected from the **File** menu in the application being used.

1 Select **Page Setup...** from the **File** menu.
The **Page Setup** dialog box appears.

2 Select this printer in the **Format for** pop-up menu.

You can select the following sections from the **Settings** pop-up menu.

Section	Description
Page Attributes	This is used to specify the settings for the paper size, scaling, and print orientation.
Custom Paper Size	This is used to specify a custom paper size.
Summary	This is used to check the current settings.
Save As Default	This is used to save the new settings as the defaults.

Page Attributes Options

The **Page Attributes** section is used to specify the settings for the paper size, scaling, and print orientation.



- Paper Size
  Select the desired paper size from the Paper Size pop-up menu.
- Orientation
  Select either a vertical or horizontal page orientation for printouts.
- Scale
  If you want to enlarge or reduce the size of the printout, enter the scale ratio here (1-400%)

Regardless of which paper size is selected, the printer does not print within 0.157" (4 mm) of the edge of the paper.

Custom Paper Size Options

The **Custom Paper Size** section is used to specify the dimensions for a custom paper size.



- New
  Click this button to create a new custom paper size.
- Duplicate
  Click this button to duplicate (copy) the settings of an existing custom paper size and create a new custom paper size based on those settings.
- Delete
  Click this button to delete a custom paper size.
- Save
  Click this button to save the settings for the selected custom paper size.
- Paper Size
  Enter the dimensions of the paper height and width for the custom paper size.

  Height: 5.9 - 14.0" (148 -356 mm)

  Width: 3.6 - 8.5" (92 - 216 mm)
- Printer Margins
  Enter the dimensions for the top, left, right, and bottom margins.

Summary

The **Summary** is used to check the currently selected Page Attributes settings.



Specifying Print Settings

The following dialog box appears when **Print...** is selected from the **File** menu in the application being used.

1 Select **Print...** from the **File** menu.
The **Print** dialog box appears.

2 Select this printer in the **Printer** pop-up menu.
The Print dialog box is used to specify the following print options.

Print Dialog Box



Section	Description
Copies & Pages	This section contains options for the number of copies to be printed and the range of pages to print.
Layout	This section contains options for specifying the page layout when printing and the setting for double-sided printing.
Output Options	This section contains options for saving the print image as a file and for the format of saved data.
Scheduler	This section contains options for specifying the print timing and priority of jobs.
Paper Handling	This section contains options for specifying the pages to be printed and their printing order.
ColorSync	This section contains options for specifying ColorSync settings.
Cover Page	This section contains options for specifying cover page settings.
Error Handling	This section contains options for specifying how an error is reported.
Paper Feed	This section contains paper feed options.
Color Options	This section contains options for color printing.

Section	Description
Printer Features	This section contains options for specifying whether or not paper of the nearest size is automatically detected when no paper tray is loaded with paper of the same size as the document and for specifying how the back of the paper is printed.
Summary	This is used to check the current settings.

No warning message will be displayed if options cannot be used together are selected.

Common buttons

- ? (Help button)
  This displays help information about the Print dialog box.
- Preview
  Click this button to view a preview image of the printout, to check that the print options are set correctly.
- Save As PDF...
  Click this button to save the print output as a PDF file.
- FAX
  Click this button to apply the changes to the settings and to send a fax.
- Cancel
  Click this button to close the Print dialog box without applying any of the settings.
- Print
  Click this button to print using the selected print options.

Copies & Pages

The **Copies & Pages** section is used to specify the number of copies to print and the range of pages to print.



- Copies
  This specifies the number of copies to be printed. If the **Collated** check-box is selected, all pages in the documents are printed as sets of print-outs.
  For example, if 5 is entered for **Copies** and **Collated** is selected, the document is printed five times from the first page to the last page.
- Pages

  All: Prints all pages in the document.

  From, to: Specifies the range of pages to be printed.

Layout

The **Layout** section is used to specify the page layout when printing and the setting for double-sided printing.



- Pages per Sheet
  Specifies the number of pages to be printed on one sheet of paper. For example, if **2** is selected, two pages are printed on one sheet of paper.
- Layout Direction
  If you are printing more than one page per sheet, this specifies the direction and order the pages should be arranged on each sheet of paper.
- Border
  This prints a border around the image for each of the pages printed on one sheet of paper when more than one page is printed on one sheet of paper.
- Two Sided Printing
  Select the desired setting for double-sided printing when the optional duplexing unit is installed.

  Off: Double-sided printing is not performed.

  Long-Edge Binding: Double-sided printing is performed with the binding along the long edge of the paper.

  Short-Edge Binding: Double-sided printing is performed with the binding along the short edge of the paper.

*To print on both sides of the paper, **Duplex Unit** must be selected under **Installable Options** (p. 20).*
*The **Long-Edge Biding** check box or **Short-Edge Biding** check box can be selected even when the **Duplex Unit** is not installed. However, in this case, the print job will be cancelled.*

Output Options

The **Output Options** section is used to specify whether or not to save the print output as a file, and the data format to use when saving the data.



- Save as File
  Select this option to save the print output as a file.
- Format
  Select the data format to be used when saving the print output as a file.

Scheduler

The **Scheduler** section is used to specify the timing and priority for printing jobs.



- Print Document

  Now: Select this option to begin printing immediately.

  At: Specify the time to begin printing.

  On Hold: Select this option to hold the print job.

- Priority

  Select the priority for printing jobs that are being held.

Paper Handling

The **Paper Handling** section is used to specify the pages that are to be printed and the order in which the pages are printed.



- Reverse page order
  Select this check box to print in the reverse page order.
- Print

  All pages: Select this option to print all pages.

  Odd numbered pages: Select this option to print only the pages with odd page numbers.

  Even numbered pages: Select this option to print only the pages with even page numbers.

ColorSync



- Color Conversion
  Allows you to select host-based color matching or printer-based color matching.
- Quartz Filter
  Allows you to select Quartz Filter.

Cover Page

- Print Cover Page
  Allows you to set cover page before or after document.
- Cover Page Type
  Allows you to select cover page type.

- Billing Info
  Allows you to set billing information printed on cover page.

Error Handling



- PostScript Errors
  Allows you to select whether or not a report is outputted when a PostScript error occurs.
- Tray Switching
  This feature is not available with this printer.

Paper Feed

The **Paper Feed** section is used to specify the paper feed setting.

- All pages from
  All pages in the document are printed using the paper in the specified paper tray.
- First page from
  The first page of the document is printed on paper from a paper tray different from the tray used to print the rest of the document.
- Remaining from
  The rest of the document is printed from the specified paper tray when the first page is to be printed on paper from a different tray.

*If an optional tray is installed, select **Unit 3** or **Unit 3 + Unit 4** under **Installable Options** (p. 20). If **Unit 3** or **Unit 3 + Unit 4** is not selected, **Tray 3** and **Tray 4** appear in gray and cannot be selected.*

Color Options



- Quick Color
  Allows you to select a color preset.
- Brightness
  Allows you to set Brightness.
- Paper Type
  Allows you to select Paper Type.
- Color as Grayscale
  Allows you to set Grayscale color.
- Color Separation
  Allows you to set Color Separation.
- Advanced Color Options
  Click this button to display the **Advanced Color Options** pane.

Advanced Color Options/Image



- RGB Source
  Allows you to select RGB color profiles for images.
- RGB Intent
  Allows you to select color intent for RGB images.
- RGB Gray Treatment
  Allows you to select RGB gray treatment for images.
- Halftone
  Allows you to select halftone for images.
- Hide Advanced Options
  Click this button to hide the **Advanced Color Options** pane and display the **Color Options** pane.

Advanced Color Options/Text



- RGB Source
  Allows you to select RGB color profiles for text.
- RGB Intent
  Allows you to select color intent for RGB text.
- RGB Gray Treatment
  Allows you to select RGB gray treatment for text.
- Halftone
  Allows you to select halftone for text.
- Hide Advanced Options
  Click this button to hide the **Advanced Color Options** pane and display the **Color Options** pane.

Advanced Color Options/Graphics



- Graphics setting
  Allows you to select settings for Graphics.
- Hide Advanced Options
  Click this button to hide the **Advanced Color Options** pane and display the **Color Options** pane.

Advanced Color Options/Simulation



- Simulation Profiles
  Allows you to select color profiles for simulation.
- Match Paper Color
  Allows you to set Match Paper Color.
- CMYK Gray Treatment
  Allows you to select Simulation gray treatment.
- Hide Advanced Options
  Click this button to hide the **Advanced Color Options** pane and display the **Color Options** pane.

Printer Features



- Nearest Size and Scale
  If no paper tray contains paper of the specified size, the page is automatically enlarged or reduced and paper of the most appropriate size is selected.
- Manually Print on 2nd Side
  This feature must be set when you set paper already printed on the front side.

Summary

The **Summary** is used to check the currently selected print settings.



Troubleshooting

Symptom	Solution
The setting in the saved presets are not applied.	Depending on the functions selected for the printer, some preset settings are not saved.
Media type error appears.	If a media type, such as “Transparency,” is specified for Tray 1, Tray 2 or Tray 3, a media type error appears and the printer stops. Be sure to specify a media type supported by Tray 1, Tray 2 and Tray 3.
The printer stops responding.	Depending on the operating system, some paper size and paper type combinations are not permitted. If the job was sent with an incorrect combination of settings, the printer stops responding. Be sure to print with the correct combination of paper size and paper type settings.
Checking the version number of the printer driver and PPD file.	■ For Mac OS X 10.4: Select the printer from **Printer Setup Utility**, and then click **Show Info** in the **Printers** menu. In the pop-up menu of the **Printer Info** dialog box, select **Name & Location**.
The dialog box displays incorrectly after you select another manufacture’s printer and then select the magicolor 5450 again.	Close the Print dialog box, and then open it again.
The custom paper size is different from the size that was set.	Depending on the operating system, the custom paper size settings may change slightly (for example, 5.80" may change to 5.79").
When printing 2 pages on a single sheet of paper, the pages are not centered on the paper.	Depending on the operating system, the pages are not centered on the paper when printing two pages on a single sheet of paper with the following paper sizes. Legal, Letter Plus, Foolscap, Government Legal, Statement, Folio

Symptom	Solution
The specified name cannot be used for the name of a custom paper size.	Due to the limitations of Mac OS X, the following names cannot be used as custom paper size names. Specify a different name. ■ “Custom” ■ General paper size names specified in the PPD files, such as “A4” and “B4”
When printing multiple copies of multiple pages on a single sheet of paper with **Collated** selected, the pages are printed continuously.	When printing multiple copies of multiple pages on a single sheet of paper, **Collated** cannot be selected.
While printing from Acrobat Reader, the pages are not correctly collated or the print job is cancelled.	If a printing error occurs with Acrobat Reader, print using the Preview application provided by the operating system.

2

Operation on Mac OS 9

System Requirements for the Printer Driver

Before installing the printer driver, make sure that your system meets the following system requirements.

Computer	Apple Macintosh computer with a PowerPC G3 or later processor (PowerPC G4 or later is recommended)
Connection between computer and printer	USB connection Network connection (10Base T/100Base TX/1000Base T)
Operating system	Mac OS 9.1 or later Mac OS X Classic mode (9.2.2 or later) When using the Classic environment of Mac OS X, Mac OS X 10.2.6 or later is required.
RAM	More than OS recommendation (128 MB or more is recommended)
Available disk space	256 MB or more is recommended (for storing images)

Installing the Printer Driver

1 Double-click the **mc5450PS OS9 Installer** icon.

The installer for the printer driver starts up.

When using Mac OS X, start up the Classic environment before installing the printer driver.

2 Check the details of the License Agreement, and click **Accept** if you agree to the terms of the license.


License
Program License Agreement
NOTICE TO USER. Please carefully read the License Agreement before using or copying this software package. The right to use this software product is conditional on your agreement on the following terms. Copying and using this software indicates that you have accepted these terms and conditions. If you do not agree to the terms of the License, you may return this software package along with the other components of this product to the place of purchase, and you will be reimbursed or credited according to the policy of the reseller or representative of KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. or its affiliate company (hereinafter collectively "KONICA MINOLTA") from whom you obtained this product. You assume responsibility for the selection of this product to achieve your intended results. Furthermore, you are responsible for installation, use, and results obtained from the product.
LICENSE AGREEMENT.
In consideration of payment of the license fee, which is a part of the purchase price, KONICA MINOLTA grants to you a non-exclusive right to use the software subject to the following conditions:
Print...
Save As...
Decline
Accept

3 Click **Install**.

The installer installs the printer driver.



Installation starts.

4 After the installation has been completed, click **Quit**.

Installation was successful. If you are finished, click Quit to leave the Installer. If you wish to perform additional installations, click Continue.
Continue
Quit

This completes the installation of the magicolor 5450 printer driver.

Selecting the Printer in the Chooser

Use the Chooser to use AppleTalk to connect the printer.

1 Use an 10Base-T/100Base-TX/1000Base-T cable to connect the printer to a Ethernet network.

2 Select **Chooser** from the Apple menu.



When using Mac OS X, the Apple menu is available with the icon for the Classic environment in the menu bar.



To display the Classic status in the menu bar, select the "Show Classic status in menu bar" check box in the Classic dialog box.

3 Select the **LaserWriter 8** icon from the icons on the left side of the Chooser.

*The printer name appears in the **Select a printer** section on the right side of the Chooser.*



4 Select the printer.

5 Click **Setup**.

6 Select **KONICA MINOLTA mc5450PS en**, then click **Select**.

The printer setup dialog box appears.



For operating systems other than those in English, select the printer indicated below, according to the language of the operating system.

- Czechoslovakian: KONICA MINOLTA mc5450PS cs
- German: KONICA MINOLTA mc5450PS de
- Spanish: KONICA MINOLTA mc5450PS es
- French: KONICA MINOLTA mc5450PS fr
- Italian: KONICA MINOLTA mc5450PS it
- Japanese: KONICA MINOLTA mc5450PS ja
- Korean: KONICA MINOLTA mc5450PS ko
- Portuguese: KONICA MINOLTA mc5450PS pt_BR
- Simplified Chinese: KONICA MINOLTA mc5450PS zh_CN
- Traditional Chinese: KONICA MINOLTA mc5450PS zh_TW

7 Select the options that are installed, and then click **OK**.

*The **KONICA MINOLTA magicolor5450** icon appears on the desktop.*

In the Classic environment, no icon appears on the desktop.

Selecting the Printer in the Desktop Printer Utility

Use the Desktop Printer Utility to use a USB cable to connect the printer.

1 Use the USB cable to connect the printer and your computer.

2 From Hard Disk, select Desktop Printer Utility.

3 Select **LaserWriter 8** from **With** pop-up menu.

4 Select **Printer (USB)** from **Create Desktop** list.

5 Click **OK**.

6 Select **Change** to select the PPD file.



7 Select **KONICA MINOLTA mc5450PS en** from the list of PPD files.



8 Click **Select**.

9 Click **Change** to select the USB Printer.



10 Select **magicolor 5450** from the **Select a USB Printer** list.



11 Click **OK**.

12 Click **Create**.



13 Select **Save** from the **File** menu.

14 Click **Save**.

15 Specify a printer name in the **Save desktop printer as** text box, and then click **Save**.



The icon for magicolor 5450 appears on the desktop.

In the Classic environment, no icon appears on the desktop.

Specifying Page Setup Settings

The **Page Setup** dialog box appears when **Page Setup...** is selected from the **File** menu.

Page Attributes Options

The **Page Attributes** section is used to specify the options for the Paper Size, scaling, and page orientation.



- Paper
  Select the desired Paper Size from the **Paper** pop-up menu.
- Scale (%)
  If you want to enlarge or reduce the size of the printout, enter the scale ratio (25%-400%) here.
- Orientation
  Select either a vertical or horizontal page orientation for printouts.

Regardless of which paper size is selected, the printer does not print within 0.157 inch (4 mm) of the edge of the paper.

Specifying a Custom Paper Size

You can also specify a paper size that is not listed in the **Paper Size** pop-up menu.

1 Select **Custom Paper Sizes...** from the pop-up menu, in the **Page Setup** dialog box.



*The **Edit Paper Sizes** dialog box appears.*

2 Click **New**.

The following dialog box appears.



3 Enter a name for the custom paper size in the **Custom Page Size Name** field, enter the dimensions in the **Width** and **Height** fields, enter the margins in **Margins** fields, and then click **OK**.

*The default units used for the dimensions for **Width**, **Height and Margins** is inches. To specify the dimensions in millimeters, select **cm** or **pts** from the **Units** pop-up menu.*

4 To add several different custom paper sizes, click **New** and repeat step 3.

*To delete an existing custom paper size, select the custom paper size from the list on the center of the dialog box, and then click **Delete**.*

5 The custom paper size setting is saved, and the name of the custom paper size can now be selected from the **Paper** pop-up menu.

6 After you have finished entering the settings, click **Done**.

Specifying Print Settings

The following dialog box appears when **Print...** is selected from the **File** menu in the application being used.



You can specify the following options from the **Print** dialog box.

Print Dialog Box Options

Section	Description
General	This section contains options for the number of copies to be printed, the paper source, and the range of pages to be printed.
Background Printing	This section contains options for spooling the print data for background or foreground printing and the document printing time.
Color Matching	This section contains options for Color Matching.
Cover Page	This section contains for specifying cover page settings.
Font Settings	This section contains options for Font Documentation and Font Down loading.
Job Logging	This section contains options for creating a job log.
Layout	This section contains options for the number of pages per sheet of paper and other duplex printing.
Save as File	This section contains options for saving the print image as a file and for the format of saved data.
Watermark	This section contains options for watermark settings.
Job Retention	This section contains options for Job Retention.
Color Options	This section contains options for color printing.
Advanced Options 1	This section contains options for advanced color.
Advanced Options 2	This section contains options for Simulation Profile.
Printer Features	This section contains options for specifying whether or not paper of the nearest size is automatically detected when no paper tray is loaded with paper of the same size as the document and for specifying how the back of the paper is printed.

No warning message will be displayed if options that cannot be used together are selected.

Common buttons

- Preview
  Click this button to view a preview image of the printout, to check that the print options are set correctly.
- Cancel
  Click this button to close the Print dialog box without applying any of the settings.
- OK
  Click this button to print using the selected print options.
- Save Settings
  Click this button to save configuration changes made in the print dialog. These changes remain as the default settings until the configuration items are changed again.

General Options



- Copies
  Allows you to specify how many copies of the print job you want printed.
- Collated
  If this item is selected, your print job is collated (one complete copy of the document is printed before the next copy is printed). Left unselected, the printing is uncollated.
- Pages
  Select **All** to print all pages in the open document. To print a specific range of pages, select **From**, and then enter the beginning page number in the **From** text box and the ending page number in the **To** text box.
- Paper Source
  Allows you to select the tray that the printer uses for the print job and to choose a different tray for the first page of the document, if you have more than one tray installed.

Background Printing



- Print In
  Allows you to choose between printing in foreground and printing in background. Printing in background creates a spool file that is temporarily saved on your computer until the print job is ready to be processed. This allows you to continue working in your applications while the print job is processing. If you don't have enough free file space on your computer to process a spool file, select Foreground printing.
- Print Time
  Allows you to assign a priority status to the print job and specify a particular time that the print job should be printed.

Color Matching



- Print Color
  Allows you to choose from the color configurations available on your computer.
- Intent
  Allows you to specify the color matching configuration or allow for automatic configuration. This item is disabled (grayed out) unless **ColorSync Color Matching** is the selected **Print Color** setting.
- Printer Profile
  Allows you to select from the printer profiles that are available.

Cover Page



- Print Cover Page
  Lets you choose whether to print a cover page, and specify Page the placement of the cover page in relation to the remaining pages of the print job.
- Cover Page Paper Source
  Allows you to select the paper tray containing the cover Paper Source page media. The Cover Page contains information about the print job such as: user name, application, document name, date, time, printer, and number of pages. This option is disabled (grayed out) if **Print Cover Page** is set to **None**.

Font Settings



- Font Documentation
  - Annotate Font Keys: Allows you to determine if the font keys are annotated.
- Font Downloading
  - Preferred Format: Allows you to select the preferred font format.
  - Always download needed fonts: If selected, fonts should always be downloaded to the printer. Printer fonts are not used.
  - Never generate Type 42 format: If selected, Type 42 fonts are not generated.
  - Use Defaults: Restores factory default settings for font downloading.

Job Logging



- If there is a PostScript error
  Allows you to select whether or not a report is outputted when a PostScript error occurs.
- Job Documentation
  Allows you to specify generating a job copy in the folder specified as the Job Documentation Folder, and generating a job font log following the completion of the print job.
- Job Documentation Folder
  Allows you to select the location of the Job Documentation Folder. The folder selected holds a copy of the print jobs or job information of print jobs that are configured for job documentation. Use the **Change** button to browse to and select a different folder.

Layout



- Pages Per sheet
  Allows you to set the number of logical pages per physical sheet.
- Layout direction
  Lets you identify either left-right or right-left logical page direction on the physical sheet.
- Border
  Allows you to select a border to surround each logical page.
- Print on Both Sides
  Allows you to configure the print job for duplex printing.
  This setting is disabled (grayed out) unless an optional duplex unit is installed.
- Binding
  Determines the orientation of the logical pages on the physical sheet so the printed media is oriented for binding on the short edge or long edge of the media.

Save as File



- Format
  Select the file format of the output file.
- PostScript Level
  Allows you to select from available PostScript levels.
- Data Format
  Sends the print job data to the file in either ASCII or Binary format.
- Font Inclusion
  Allows you to choose the fonts that are included with the Inclusion print job as it is saved to a file.

Watermark



- Text
  Allows you to select watermark text.
- Font
  Allows you to select watermark font type.
- Size
  Allows you to select watermark font size.
- Color
  Allows you to select watermark font color.
- Transparent
  Allows you to set watermark transparency.
- Position
  Allows you to select watermark position.

Job Retention



- Job Retention
  Select type of job.
  - Print: The job is printed normally.
  - Secured Job: Printer dose not print the job without the panel operation. Printer prints the job when you input Security ID correctly. The job is deleted after all copies are printed.
  - Stored Job: Printer dose not print the job without the panel operation. You can print desired copies through the panel. You can print additional copies through the panel later. If you stored the job with securityID, you have to input it every time print job. Printer keeps the job until it is deleted intentionally.
  - Print and Hold: Printer prints all of multicopy print job, and then holds the print job in the printer's hard disk for printing additional copies. The job isn't deleted until it is intentionally deleted or the held job timeout occurs.
  - Proof then Print: Printer prints 1 copy without the panel operation. You can then print the rest of the copies through the panel. The job is deleted after the whole copies are printed.

  For details on each printing procedure, refer to the magicolor 5450 User's Guide.
- Job Name
  Allows you to set Job Name.
- User Name
  Allows you to set User Name.

- Security ID
  Select a Security ID to a Job.

To use Job Retention feature, the optional Hard Disk must be installed on the printer.

In addition, the printer must be set up with the Chooser to use the Hard Disk. For details on selecting the Hard Disk with the Chooser, refer to “Selecting the Printer in the Chooser” on page 48.

Color Options



- Brightness
  Allows you to set Brightness of the image.
- Paper Type
  Allows you to select Paper Type.
- Color as Grayscale
  Allows you to set Grayscale color.
- Color Separation
  Allows you to set Color Separation.

Advanced Options 1



- RGB Source
  Allows you to select RGB color profiles for images and text.
- RGB Intent
  Allows you to select RGB intent for images and text.
- RGB Gray Treatment
  Allows you to select RGB gray treatment for images and text.
- Halftone
  Allows you to select halftone for images and text.
- Graphics
  Select settings for graphics.

Advanced Options 2



- Simulation Profiles
  Allows you to select RGB color profiles for simulation.
- Match Paper Color
  Allows you to set Match Paper Color.
- CMYK Gray Treatment
  Allows you to select CMYK gray treatment.

Printer Features



- Nearest Size and Scale
  If no paper tray contains paper of the specified size, the page is automatically enlarged or reduced and paper of the most appropriate size is selected.
- Manually Print on 2nd Side
  This feature must be set when you set paper already printed on the front side.

Checking Print Jobs

To check the progress of print jobs, double-click the **magicolor 5450** desktop printer icon.



In the Classic environment, Print Monitor automatically starts up, and the icon appears in the Dock. Click the Print Monitor icon to check the status of print jobs.

Troubleshooting

Symptom	Action
When printing on both sides of paper with a custom size, an error occurs.	Both sides of paper with a custom size cannot be printed on. In addition, there are limitations on the media types that can be selected. Refer to the User's Guide (CD-ROM) provided with the printer.
When printing from a Web browser, each frame is printed on a separate page.	Depending on the Web browser being used, each frame will be printed on a separate page. Try printing from a different Web browser. You can confirm it using the "preview" function of the print dialog.
Double-sided printing cannot be selected.	If the printer is connected by USB, select the installed options with the Chooser. For details on selecting options with the Chooser, refer to "Selecting the Printer in the Chooser" on page 48. In addition, there are limitations on the media types that can be selected. Refer to the User's Guide (CD-ROM) provided with the printer.
Tray 3 cannot be selected.	
The error was cancelled, but the error message appeared again.	Occasionally, the error message appears a few times, even though the error was cancelled.

3 Operation on Linux

System Requirements for the Printer Driver

Before installing the printer driver, make sure that your system meets the following system requirements.

Operating systems	Red Hat Linux 9.0, SuSE Linux 8.2
Connecting the computer and printer	USB connection, Parallel connection, Network connection (10Base-T/100Base-TX/ 1000Base-T)
RAM	More than OS recommendation (128 MB or more is recommended)
Network	LPR (queue: lp, LP, default, DEFAULT)
	AppSocket/HP JetDirect
Available hard disk space	256 MB or more

As an example, the descriptions of the operations for Red Hat 9.0 are provided in this chapter.

Installing PPD File From the Command Line

Before proceeding with the installation, be sure to exit all running applications.

Root privileges are required in order to install ppd file.

1 Copy the ppd file from the Software Utilities CD-ROM to the "/usr/share/cups/model/KONICA MINOLTA/" on the computer.

A ppd file for each language is available in the corresponding "drivers/linux/ppd/<language>" folder on the CD-ROM. Use the appropriate ppd file for the language.

When printing from OpenOffice, use M5450opn.ppd. Otherwise, use M5450PX.ppd.
For details on the procedure for printing from OpenOffice, refer to "Example Using OpenOffice" on page 88.

2 From the Main Menu, select **System Tools**, then **Terminal**.

3 Enter the command "/etc/init.d/cups restart".


root@localhost:~
File Edit View Terminal Go Help
[root@localhost root]# cp /mnt/cdrom/drivers/linux/ppd/english/M545OPX.ppd /usr/share/cups/model/KONICA\ MINOLTA/
[root@localhost root]# /etc/init.d/cups restart
Stopping cups: [OK]
Starting cups: [OK]
[root@localhost root]#

4 Quit Terminal.

Adding the Printer

After copying the PPD file, be sure to restart CUPS.

1 Start up the Web browser.

2 Enter the URL “http://localhost:631”, and then click **Manage Printers**.
The CUPS Administration Web page appears.


Printer on localhost - CUPS v1.1.17 - Mozilla
File Edit View Go Bookmarks Tools Window Help
ESP
Administration
Classes
Help
Jobs
Printers
Software
Printer
No printers
Add Printer
Copyright 1993-2002 Easy Software Products, All Rights Reserved. The Common UNIX Printing System, CUPS, and the CUPS logo are the trademark property of Easy Software Products. All other trademarks are the property of their respective owners.

3 Click **Add Printer**.
A pop-up window appears.



4 Enter the user name and password for using root privileges, and then click **OK**.

5 Enter the printer name, location, and description, and then click **Continue**.

6 Select a Device Port from the Device list, then click **continue**.

- TCP/IP: AppSocket/HP JetDirect



- USB: USB Printer #1 (KONICA MINOLTA magicolor 5450)

- Parallel: Parallel Port #1

7 For a USB or parallel connection, skip to step 8. Enter the device URI in the following form: socket://<Printer IP or Printer Hostname>[:port]



Example:
Using Printer IP - socket://192.168.1.190:9100
Using printer Hostname - socket://Hostname:9100
Hostname may be substituted by IP Address, and Port is optional.

8 Click **Continue**.

9 Select **KONICA MINOLTA**, click **Continue**.



10 Select **KONICA MINOLTA mc5450 PPD (en)**, then click **Continue**.



The following message appears.


Admin on localhost - CUPS v1.1.17 - Mozilla
File Edit View Go Bookmarks Tools Window Help
Back Forward Reload Stop
http://localhost:631/admin
Search Print
ESP
Administration Classes Help Jobs Printers Software
Admin
Printer mc5450 has been added successfully.
Copyright 1993-2002 Easy Software Products, All Rights Reserved. The Common UNIX Printing System, CUPS, and the CUPS logo are the trademark property of Easy Software Products. All other trademarks are the property of their respective owners.
Done

Specifying Printer Driver Settings

Displaying the Settings Page

1 Start up the Web browser.

2 Enter the URL “http://local-host:631”, and then click **Manage Printers**.
Printer on localhost.local-domain *window appears.*


Printer on localhost - CUPS v1.1.17 - Mozilla
File Edit View Go Bookmarks Tools Window Help
ESP Administration Classes Help Jobs Printers Software
Printer
Default Destination: mc5450
mc5450 KONICA MINOLTA mc5450 PPD
Description: KONICA MINOLTA magicolor 5450
Location:
Printer State: idle, accepting jobs.
Device URI: socket://192.168.1.193:9100/
Print Test Page Stop Printer Reject Jobs Modify Printer Configure Printer Delete Printer
Add Printer
Copyright 1993-2002 Easy Software Products, All Rights Reserved. The Common UNIX Printing System, CUPS, and the CUPS logo are the trademark property of Easy Software Products. All other trademarks are the property of their respective owners.

3 Click **Configure Printer**.
The printer driver settings page appears.



Printer Driver Settings

Extra

Parameters	Settings
Brightness	Specifies the brightness of the image as **-15%**, **-10%**, **-5%**, **0%**, **+0.5%**, **+10%**, or **+15%**. ■ The default setting is **0%**.
Choose Resolution	Displays the image resolution (High Quality) for printing.
Color Separation	Specifies the color separation as **Yes** or **No**. ■ The default setting is **No**.
Graphics	Specifies the settings for graphics as **Same as Text settings** or **Same as Image Settings**. ■ The default setting is **Same as Image Settings**.
Nearest Size and Scale	If no paper tray contains paper of the specified size, the page is automatically enlarged or reduced and paper of the most appropriate size is selected. ■ The default setting is **Yes**.
Select Color	Specifies the color for printing as **Color** or **Gray Scale**. ■ The default setting is **Color**.

General

Parameters	Settings
Collate	If **Yes** is selected, all pages in the documents are printed as sets of printouts. ■ The default setting is **No**.
Duplex Options	Specifies the duplex print binding position as **Simplex**, **Long Edge**, or **Short Edge**. ■ The default setting is **Simplex**

Parameters	Settings
Paper Sizes	Specifies the paper size. An irregular paper size cannot be selected.
Paper Source	Specifies the paper source as **Tray 1**, **Tray 2**, **Tray 3**, **Tray 4**, **Tray 1 (Manual Feed)**, or **Auto**. ■ The default setting is **Tray 1**.
Paper Type	Specifies the paper type as **Printer Default**, **Plain Paper**, **Recycled**, **Transparency**, **Glossy**, **Label**, **Thick 1 (91 - 150g/m2)**, **Thick 2 (151 - 216g/m2)**, **Letterhead**, **Envelope**, or **Postcard**. ■ The default setting is **Printer Default**.

Image Options

Parameters	Settings
Image Halftone	Specifies the halftone for image as **Line Art**, **Detail**, or **Smooth**. ■ The default setting is **Detail**.
Image RGB Gray Treatment	Specifies the RGB Gray Treatment as **Composite Black**, **Black and Gray**, or **Black Only**. The default setting is **Composite Black**.
Image RGB Intent	Specifies RGB intent for image as **Vivid**, **Photographic**, **Relative Color**, or **Absolute Color**. ■ The default setting is **Photographic**.
Image RGB Source	Specifies RGB source for image as **None**, **sRGB**, **Adobe RGB (1998)**, **Apple RGB**, **ColorMatch RGB**, or **Blue Adjust RGB**. ■ The default setting is **sRGB**.

Options Installed

Parameters	Settings
Printer Memory	Select **256 MB**, **512 MB**, **768 MB**, or **1024 MB** if the optional memory for the printer has been installed. ■ The default setting is **256 MB**.
Duplex Unit	Select **Enable** if the optional duplexing unit for the printer has been installed. ■ The default setting is **Disable**.
Hard Disk	Select **Enable** if the optional Hard Disk for the printer has been installed. ■ The default setting is **Disable**.
Paper Source Unit	Select **Unit 3** or **Unit 3 + Unit 4** if the optional trays for the printer have been installed. ■ The default setting is **Disable**.

Simulation Profile

Parameters	Settings
Simulation Gray Treatment	Specifies simulation gray treatment as **Composite Black**, **Black and Gray**, or **Black Only**. ■ The default setting is **Composite Black**.
Match Paper Color	Specifies the Match Paper Color. ■ The default setting is **OFF**.
Simulation Profile	Specifies the simulation profile as **None**, **SWOP**, **Euroscale**, **Commercial Press**, **DIC**, or **TOYO**. ■ The default setting is **None**.

Text Options

Parameters	Settings
Text Halftone	Specifies the halftone for text as **Line Art**, **Detail**, or **Smooth**. ■ The default setting is **Line Art**.
Text RGB Gray Treatment	Specifies the RGB Gray Treatment as **Composite Black**, **Black and Gray**, or **Black Only**. ■ The default setting is **Black and Gray**.
Text RGB Intent	Specifies RGB intent for text as **Vivid**, **Photographic**, **Relative Color**, or **Absolute Color**. ■ The default setting is **Vivid**.
Text RGB Source	Specifies RGB source for text as **None**, **sRGB**, **Adobe RGB (1998)**, **Apple RGB**, **ColorMatch RGB**, or **Blue Adjust RGB**. ■ The default setting is **sRGB**.

Banners

Parameters	Settings
Starting Banner	Specifies the starting banner as **none**, **classified**, **confidential**, **secret**, **standard**, **topsecret**, or **unclassified**. ■ The default setting is **none**.
Ending Banner	Specifies the ending banner as **none**, **classified**, **confidential**, **secret**, **standard**, **topsecret**, or **unclassified**. ■ The default setting is **none**.

Printing a Document

The contents and available options that appear in the print dialog box may vary depending on the application being used.

Example Using LPR Command

With applications other than OpenOffice, the following print dialog box appears.

1 Click **Properties** in the Print dialog box.



2 The Print Properties dialog box appears.



3 Enter the command “lpr -P” followed by the name of the printer, and then click **OK**. The Print dialog box appears again.

4 Click **Print** to print the document.

Example Using OpenOffice

The procedure for printing on Red Hat 9 with OpenOffice 1.0.2 is described below. The following procedure or some steps may be different depending on the version of the operating system being used.

First, use m5450opn.ppd to add the printer to the system. For details on adding a printer to the system, refer to "Adding the Printer" on page 80.

1 From the main menu, select **Office**, then **OpenOffice.org Printer Setup**.
The printer Administration dialog box appears.



2 Click **New Printer**.
The Add Printer dialog box appears.



3 Check that **Add a printer** is selected, and then click **Next**.
The printer selection list appears.



4 Click **Import**.

Driver Installation dialog box appears.



5 Enter “/usr/share/cups/model/KONICA MINOLTA/” in the driver directory.

6 In the Selection of drivers list, select **KONICA MINOLTA mc5450 OpenOffice PPD**.

7 Click **OK**.

8 Select **KONICA MINOLTA mc5450 OpenOffice PPD**, and then click **Next**.

9 In the command line, enter “lpr -P” followed by the name of the printer added first, then click **Next**.



10 Change the printer name.



11 Click **Finish**. The Printer Administration dialog box appears again.

12 Click **Close**.

13 From the main menu, select **Office**, then **OpenOffice.org Writer**.

14 Click **Print** in the **File** menu.
The Print dialog box appears.



15 Select the name of the printer specified in the **OpenOffice** printer settings.



16 Click **OK**.

The kprinter Print dialog box appears.

Checking Print Jobs

You can check the status of print jobs from a Web browser.

1 Start up the Web browser.

2 Enter the URL “http://local-host:631”.
The CUPS Administration Web page appears.



3 Click **Manage Jobs**.
A list of the currently active print jobs appear.


Jobs on localhost - CUPS v1.1.17 - Mozilla
File Edit View Go Bookmarks Tools Window Help
ESP
Administration
Classes
Help
Jobs
Printers
Software
Jobs
No Active Jobs
Show Completed Jobs
Copyright 1993-2002 Easy Software Products, All Rights Reserved. The Common UNIX Printing System, CUPS, and the CUPS logo are the trademark property of Easy Software Products. All other trademarks are the property of their respective owners.

*To check the status of completed print jobs, click **Show Complete Jobs**.*

Troubleshooting

Symptom	Action
The printer stops because of a paper size error or a paper type error.	The job may have been sent with a prohibited combination of settings (for example, for the paper size and media type). Printing is not possible with postcards or overhead projector transparencies if **Plain Paper** is selected.
Printing does not continue with a custom paper size.	Printing with custom paper sizes is not possible directly from the printer driver. This can only be performed from the command line. Specify the following command to print data. lpr -P *[printer_name]* -o media=Custom.[WIDTHxLENGTH] *[file_name]* 1. Format of Custom. [WIDTHxLENGTH]: Custom.150x200 mm, Custom.8x11 in, Custom.15x20 cm, or Custom.612x782 (postscript points) 2. The specified file must be a PS, PDF or JPEG file.
Printing cannot be completed correctly from OpenOffice or any other Office application (such as, Kword).	Applications running under Linux have their own print settings. Some of these functions may not be supported by this printer. Observe the following for best printing results. ■ Settings made within the application: Paper size and orientation ■ Settings made with the printer driver (kprinter): Settings other than those specified above (for example, paper type, tray, and resolution)
When printing from Acrobat Reader, part of the image is printed in solid black or the job is interrupted.	There is a compatibility problem between Ghostscript and Acrobat Reader. Try using a different PDF application.
Watermarks cannot be printed from Kword.	This is a bug with Kword. Use Overlay instead.

4

Printer Management Utilities

Installing Printer Management Utilities on Windows

You must have administrator privileges in order to install the Printer Management Utilities.

Before proceeding with the installation, be sure to exit all running applications.

The following procedure describes how to install the Printer Management Utilities.

- Crown Print Monitor+
- Status Monitor
- Download Manager Utility
- PageScope Network Setup

1 Insert “magicolor 5450 Software Utilities” CD-ROM in your CD/DVD-ROM drive.

2 Select **Next** from the Introduction dialog.

KONICA MINOLTA
Introduction
Dear Customer,
Thank you for investing in a Konica Minolta printer. Please register your printer to ensure the best support and warranty service.
Administrative rights are required to perform this function.
Please logon with an account that has Administrative access to this workstation.
magicolor 5450
printer.konicaminolta.com

3 From the Main Menu dialog, select **Additional Software**.

4 After reviewing and accepting the license agreement, choose the installation directory (or use the default directory setting).

5 Select **Custom**, then click **Next**.


KONICA MINOLTA Printer Software Installer
Choose the setup type that best suits your needs.
Easy
Install the product in the configuration recommended for the typical user. This satisfies the needs of most users.
Custom
List all available components, and allow me to choose which ones to install.This is provided for advanced users. Individual features within eac product can be selected and installed.
InstallShield
< Back
Next >
Cancel

*Click **Easy** to install all printer management utilities.*

6 Select **KONICA MINOLTA Printer Management Utilities** from the **Product** list, and select **Custom** from **Setup Type** pull down list, then click **Next**.


KONICA MINOLTA Printer Software Installer
From this list, please select the products to install.
All products that are checked will be installed.
-
Also choose how to install the selected products.
Typical setup is recommended for most users.
Custom setup allows you to select which features to install.
Product
Setup Type
KONICA MINOLTA magicolor 5450 Printer Driver Software
Typical
KONICA MINOLTA Printer Management Utilities
Custom
KONICA MINOLTA Administrator Documentation
Typical
InstallShield
< Back
Next >
Cancel

7 From the **Product Installation** list, select the check boxes for the software to be installed, and then click **Next**.

8 Follow the onscreen instructions to complete the installation.

9 When the Information message box appears, select **Finish**.

10 After the installation is complete, remove the Software Utilities CD-ROM from your CD-ROM drive and store it in a safe place.

5

Understanding the Ethernet Configuration Menus

Ethernet Menu

Location within the Configuration Menu



Accessing the Ethernet Menu

Use the following series of keystrokes at the printer to access the Ethernet menu options on your printer. This menu provides access to all of the configurable network items.

Press this key . . .	**(until) the message window reads.** . .
* Menu Select ↵	PROOF/ PRINT MENU or if no optional hard disk is installed: PRINT MENU
▽	INTERFACE MENU
* Menu Select ↵	
▽	ETHERNET
* Menu Select ↵	

After the Ethernet settings are changed, the printer automatically reboots.

Using the Network Menu Options

If the printer is connected to a network, the following settings should be specified. For details about each setting, contact your network administrator.

When manually setting the IP address, Subnet Mask, and Gateway turn off DHCP first.

TCP/IP

Enable

Purpose	Enables or disables TCP/IP. If YES is selected, TCP/IP is enabled. If NO is selected, TCP/IP is disabled.
Options	YES NO
Default	YES

IP Address

Purpose	Sets the IP address of this printer on the network.
Range	0–255 for each *xxx* triplet Use the Up and Down keys to increase or decrease each number; use the Left and Right keys to move between triplets.
Default	000.000.000.000

Subnet Mask

Purpose	Sets the subnet mask value of the network. The subnet mask allows you to limit access to your printer (for example, according to departmental divisions).
Range	0–255 for each *xxx* triplet Use the Up and Down keys to increase or decrease each number; use the Left and Right keys to move between triplets.
Default	255.255.000.000

Default Gateway

Purpose	Sets the address of the router/gateway if a router/gateway is used on your network and you allow users outside your network environment to print on your printer.
Range	0–255 for each *xxx* triplet Use the Up and Down keys to increase or decrease each number; use the Left and Right keys to move between triplets.
Default	000.000.000.000

DHCP/BOOTP

Purpose	If there is a DHCP or BOOTP server on the network, specifies whether the IP address and other network information is automatically assigned by the DHCP or BOOTP server.
Options	YES NO
Default	YES

TELNET

Enable

Purpose	Select whether to enable or disable Telnet transmissions. When ENABLE is selected, Telnet transmissions are enabled. When DISABLE is selected, Telnet transmissions are disabled.
Options	ENABLE DISABLE
Default	ENABLE

NetWare

Enable

Purpose	Enables or disables NetWare. If YES is selected, NetWare is enabled. If NO is selected, NetWare is disabled.
Options	YES NO
Default	YES

AppleTalk

Enable

Purpose	Enables or disables AppleTalk. If YES is selected, AppleTalk is enabled. If NO is selected, AppleTalk is disabled.
Options	YES NO
Default	YES

Speed/Duplex

Purpose	Specifies the transmission speed for the network and the transmission method for bi-directional transmission.
Options	AUTO 10BASE FULL 10BASE HALF 100BASE FULL 100BASE HALF 1000BASE FULL
Default	YES

CAMERA DIRECT

Enable

Purpose	Select whether to enable or disable camera direct printing. If ENABLE is selected, camera direct printing is enabled. If DISABLE is selected, camera direct printing is disabled.
Options	ENABLE DISABLE
Default	ENABLE

6

Network Printing

Network Connection

Theory

To connect your printer in a TCP/IP network environment, you must make sure that the internal network addresses in the printer have been set.

In many cases, you have to enter only a unique IP address. However, you may also have to enter a subnet mask and/or a gateway (router) address, depending on your network configuration requirements.



Making the Connection

Ethernet Interface

An RJ45 connector can be used as the Ethernet interface for this printer.

When connecting your printer to an Ethernet network, the tasks you perform depend on how you plan to set the printer's IP (Internet Protocol) address. Printers are shipped with a preset IP address, subnet mask, and gateway.

- **IP Address**—A unique identifier for each device on a TCP/IP network.
- **Subnet Mask**—A filter used to determine what subnet an IP address belongs to.
- **Gateway**—A node on a network that serves as an entrance to another network.

Since the IP address for each PC and printer on your network must be unique, you usually need to modify this preset address so it doesn't conflict with any other IP address or your network or any attached network. You can do this in one of two ways. Each is explained in detail in the following sections.

- Using DHCP
- Setting the address manually

Using DHCP

If your network supports DHCP (Dynamic Host Configuration Protocol), the printer's IP address will be automatically assigned by the DHCP server when you turn on the printer. (Refer to "Network Printing" on page 113 for a description of DHCP.)

If your printer is not automatically assigned an IP address, verify that DHCP is enabled on the printer (`PRINT MENU/CONFIGURATION PG`). If it is not enabled, you can enable it in the `INTERFACE MENU/ETHERNET/TCP/IP/DHCP/BOOTP` menu.

1 Connect your printer to the network.

When using an Ethernet cable, plug the RJ45 connector into the Ethernet interface port of the printer.

2 Turn on your PC and printer.

3 When the printer's message window displays READY, print a configuration page to verify that the IP address is set.

Press this key . . .	(until) the message window displays . . .
	READY
* Menu Select ↵	RPOOF/ PRINT MENU
▽	PRINT MENU
* Menu Select ↵	CONFIGURATION PG
* Menu Select ↵	

4 Install the printer driver and utilities.

If the printer cannot be connected to a DHCP server, an IP address within the range between 169.254.0.0 and 169.254.255.255 is automatically set.

Setting the Address Manually

You may also manually change the printer's IP address, subnet mask, and gateway by using the following instructions. (See chapter 5, "Understanding the Ethernet Configuration Menus," for more information.)

When manually setting the IP address, turn off DHCP and BOOTP first. In addition, when the IP address is changed, add a new port or reinstall the printer driver.

CAUTION

You should always notify your network's administrator before changing the printer's IP address.

1 Turn on your PC and printer.

2 When the printer's message window displays `READY`, set the IP address.

Press this key . . .	(until) the message window reads . . .
	`READY`

* Menu Select ↵	`PROOF/`
	`PRINT MENU`
	or if no optional hard disk is installed:
	`PRINT`
	`MENU`

▽	`INTERFACE` `MENU`
* Menu Select ↵	
▽	`ETHERNET`
* Menu Select ↵	`TCP/IP`

Press this key . . .	(until) the message window reads . . .
* Menu Select ↵	
▽	IP ADDRESS
* Menu Select ↵	IP ADDRESS 000.000.000.000
Use the ▷ and ◁ keys to move to each of the four number triplets. Use the △ and ▽ keys to increase or decrease each number.	
* Menu Select ↵	IP ADDRESS xxx.xxx.xxx.xxx

3 If you don't want to set the subnet mask or gateway, go to step 5.

If you don't want to set the subnet mask, but you do want to set the gateway, go to step 4.

If you want to set the subnet mask, follow these steps.

Press this key . . .	(until) the message window displays . . .
▽	SUBNET MASK
* Menu Select ↵	SUBNET MASK 255.255.000.000

Press this key . . .	(until) the message window displays . . .
Use the ▷ and ◁ keys to move to each of the four number triplets. Use the △ and ▽ keys to increase or decrease each number.	
* Menu Select ↵	SUBNET MASK xxx.xxx.xxx.xxx

4 If you don't want to set the gateway, go to step 5.

If you want to set the gateway, follow these steps.

Press this key . . .	(until) the message window displays . . .
▽	DEFAULT GATEWAY
* Menu Select ↵	DEFAULT GATEWAY 000.000.000.000
Use the ▷ and ◁ keys to move to each of the four number triplets. Use the △ and ▽ keys to increase or decrease each number.	
* Menu Select ↵	DEFAULT GATEWAY xxx.xxx.xxx.xxx

5 Save your configuration changes and make the printer ready for printing again.

Press this key . . .	(until) the message window displays . . .
Cancel	Press the Cancel key 2 times to reboot the printer

6 After rebooting the printer, print a configuration page to verify that the correct IP address, subnet mask, and gateway have been set.

Press this key . . .	(until) the message window displays . . .
	READY
* Menu Select ↵	RPOOF/ PRINT MENU or if no optional hard disk is installed: PRINT MENU
▽	PRINT MENU
* Menu Select ↵	CONFIGURATION PG
* Menu Select ↵	

7 Install the printer driver and utilities.

Network Printing

Network printing terms are described below.

- Bonjour
- BOOTP
- DDNS
- DHCP
- HTTP
- IPP
- IPX/SPX
- LPD/LPR
- NetBEUI
- SLP
- SNMP
- Port9100
- SMB
- SMTP

This chapter contains descriptions on the network printing terms and the IPP printing methods.

Bonjour

Macintosh network technology for automatically detecting devices connected to the network and for specifying settings. Previously called “Rendezvous”, the name was changed to “Bonjour” starting with Mac OS X v10.4.

BOOTP

BOOTP (Bootstrap Protocol) is an Internet protocol that enables a diskless workstation to discover (1) its own IP address, (2) the IP address of a BOOTP server on the network, and (3) a file that can be loaded into memory to boot the workstation. This enables the workstation to boot without requiring a hard or floppy disk drive.

DHCP

DHCP (Dynamic Host Configuration Protocol) is a protocol for assigning dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network. In some systems, the device's IP address can even change while it is still connected. DHCP also supports a mix of static and dynamic IP addresses. Dynamic addressing simplifies network administration because the software keeps track of IP addresses rather than requiring an administrator to manage the task. This means that a new computer can be added to a network without the hassle of manually assigning it a unique IP address.

DDNS (Dynamic DNS)

DDNS (Dynamic Domain Name System) is technology for automatically assigning dynamically assigned IP addresses to fixed domains.

The recent availability of always-on Internet connections has resulted in an increased number of users turning their home computers into publicly accessible Web servers. The IP address supplied by the Internet service provider changes with each connection, complicating public access to the Internet.

By using a DDNS service, home computers can normally be accessed with a fixed host name.

HTTP

HTTP (HyperText Transfer Protocol) is the underlying protocol used by the World Wide Web. It defines how messages are formatted and transmitted, and what actions web servers and browsers should take in response to various commands. For example, when you enter a URL in your browser, this actually sends an HTTP command to the Web server directing it to fetch and transmit the requested web page.

IPP

IPP (Internet Printing Protocol) is a protocol for end users' most common printing situations over the Internet. It allows users to find out about a printer's capabilities, submit print jobs to a printer, determine the status of the printer or print job, and cancel a previously submitted print job.

For more information on using IPP, See “Printing via IPP (Internet Printing Protocol) – Windows Server 2003/XP/2000” on page 117.

IPX/SPX

IPX/SPX (Internetwork Packet Exchange/Sequenced Packet Exchange) is a networking protocol developed by Novell. It was used mainly in Netware environments as the general LAN protocol, where TCP/IP has become widespread.

LPD/LPR

LPD/LPR (Line Printer Daemon/Line Printer Request) is a platform-independent printing protocol that runs over TCP/IP. Originally implemented for BSD UNIX, its use has spread into the desktop world and is now an industry standard.

NetBEUI

NetBEUI (NetBIOS Extended User Interface) is a networking protocol developed by IBM. It allows small-scale networks to easily be constructed simply by specifying the computer name.

SLP

Traditionally, in order to locate services on the network, users had to supply the host name or network address of the machine providing the desired service. This has created many administrative problems.

However, SLP (Service Location Protocol) simplifies the discovery and use of network resources such as printers by automating a number of network services. It provides a framework that allows networking applications to discover the existence, location, and configuration of networked services.

With SLP users no longer need to know the names of network hosts. Instead, they need to know only the description of the service they are interested in. Based on this description, SLP is able to return the URL of the desired service.

Unicast, Multicast, and Broadcast

SLP is a unicast and a multicast protocol. This means that messages can be sent to one agent at a time (unicast) or to all agents (that are listening) at the same time (multicast). However, a multicast is not a broadcast. In theory, broadcast messages are “heard” by every node on the network. Multicast differs from broadcast because multicast messages are only “heard” by the nodes on the network that have “joined the multicast group.”

For obvious reasons network routers filter almost all broadcast traffic. This means that broadcasts that are generated on one subnet will not be “routed” or forwarded to any of the other subnets connected to the router (from the router’s perspective, a subnet is all machines connected to one of its ports). Multicasts, on the other hand, are forwarded by routers. Multicast traffic from a given group is forwarded by routers to all subnets that have at least one machine that is interested in receiving the multicast for that group.

SNMP

SNMP (Simple Network Management Protocol) is actually a set of protocols for managing complex networks. SNMP works by sending messages to different parts of a network. SNMP-compliant devices, called agents, store data about themselves in Management Information Bases (MIBs) and return this data to the SNMP requesters.

Port 9100

When printing through a network, TCP/IP port number 9100 can be used to send raw data.

SMB

SMB (Server Message Block) is a protocol for sharing resources on the network, such as files and printers, in a Windows environment.

If the Samba server software is used on Linux or UNIX, services using SMB can be shared.

SMTP

SMTP (Simple Mail Transfer Protocol) is a protocol for sending e-mail.

This protocol was originally used to send e-mail between servers; however, currently client e-mail software use it to also send e-mail to servers using POP.

Printing via IPP (Internet Printing Protocol) – Windows Server 2003/XP/2000

Adding an IPP Port using Add Printer Wizard

- For Windows Server 2003/XP: Click **Start**, select **Printers and Faxes**, and then click **Add Printer**.
- For Windows 2000: Click **Start**, point to **Settings**, click **Printers**, and then click **Add Printer**.

1 In the second dialog box select the **Network Printer** radio button and then choose **Next**.

Windows Server 2003/XP


Add Printer Wizard
Local or Network Printer
The wizard needs to know which type of printer to set up.
Select the option that describes the printer you want to use:
Local printer attached to this computer
Automatically detect and install my Plug and Play printer
A network printer, or a printer attached to another computer
To set up a network printer that is not attached to a print server, use the "Local printer" option.
< Back
Next >
Cancel

Windows 2000


Add Printer Wizard
Local or Network Printer
Is the printer attached to your computer?
If the printer is directly attached to your computer, click Local printer. If it is attached to another computer, or directly to the network, click Network printer.
Local printer
Automatically detect and install my Plug and Play printer
Network printer
< Back
Next >
Cancel

2 In the URL field in the next dialog box enter the printer's network path-name in one of the following formats and then choose **Next**:

- http://*ipaddress*/ipp
- http://*ipaddress*:80/ipp
- http://*ipaddress*:631/ipp

Port 631 is not supported by Windows 2000.

Windows Server 2003/XP


Add Printer Wizard
Specify a Printer
If you don't know the name or address of the printer, you can search for a printer that meets your needs.
What printer do you want to connect to?
Browse for a printer
Connect to this printer (or to browse for a printer, select this option and click Next):
Name:
Example: \\server\printer
Connect to a printer on the Internet or on a home or office network:
URL:
Example: http://server/printers/myprinter/.printer
< Back
Next >
Cancel

Windows 2000


Add Printer Wizard
Locate Your Printer
How do you want to locate your printer?
If you don't know the name of the printer, you can browse for one on the network.
What do you want to do?
Type the printer name, or click Next to browse for a printer
Name:
Connect to a printer on the Internet or on your intranet
URL:
< Back
Next >
Cancel

- **Windows Server 2003/XP**—"Windows cannot connect to the printer. Either the printer name was typed incorrectly, or the specified printer has lost its connection to the server. For more information, click **Help**."
- **Windows 2000**—"Could not connect to the printer. You either entered a printer name that was incorrect or the specified printer is no longer connected to the server. Click **Help** for more information."

3 **Windows Server 2003/XP**—Go to step 4.

Windows 2000—If you entered a valid path in the previous step, the following message displays: "The server on which the KONICA MINOLTA magicolor 5450 printer resides does not have the correct printer driver installed. If you want to install the driver on your local computer, click **OK**." The reason for this is that you do not yet have a printer driver installed. Choose **OK**.

4 Choose **Have Disk**, locate the directory on the CD-ROM where the printer driver files are located (for example, drivers\windows 2000, XP, 2003\ps\english), and then choose **OK**.



5 Finish installing the printer driver.

Symptom	Action
SMB printing cannot be performed well.	Follow the procedure described below to re-install the printer on a local computer. 1. Delete the printer icon from the printer folder. 2. Delete the printer driver and SMB port from the system. 3. Use the Add Printer Wizard to install the printer as a local printer. At this time, create a new local port, and specify the SMB port name.
Some client functions are not available with the Point and Print feature when the server is running Windows XP/Server 2003/2000 and the client computer is running Windows NT 4.0.	Install the printer driver directly on the client computer.

7

Using Crown Print Monitor+

Adding a Crown Port After Installing Crown Print Monitor+

After Crown Print Monitor+ is installed, a Crown port can be added by following the procedure described below.

The following procedure provides a description when Crown Print Monitor+ is already installed on the computer.

For Windows XP, 2000 and NT 4.0:

1 Click **Start**, and then click **Printers and Faxes**.

*For Windows 2000 and Windows NT 4.0, click **Start**, point to **Settings**, and then click **Printers**.*

2 Right-click the printer icon, and then click **Properties**.

*The **Properties** dialog box for the printer appears.*

3 Click the **Ports** tab.

4 Click **Add Port**.

*The **Printer Ports** dialog box appears.*

5 From the **Available port types** list, select **Crown Port+**, and then click **New Port**.

*The **Add Crown Port+** dialog box appears.*

*For Windows NT 4.0, select **Crown Port+** from the **Available Printer Ports** list.*



6 In the **IP Address** text box, type the IP address for the printer.

For this address, type in a unique host name or the dot notation identifier (IP address) for the printer.

The printer search function is not supported with this printer.

7 In the **Port Name** text box, type the logical name of the port.

The logical name of the port is the description identifier for the port. Each port name must be unique.

A maximum of 128 characters can be entered for the port name.

*If nothing is entered in the IP Address text box, the text entered in the **Port Name** text box is added to the IP Address text box. Change the text as necessary.*

8 Click **OK**.

*Click **Advanced** to display the **Configure Crown Port+** dialog box, and then specify the advanced settings for the Crown port. For details, refer to "Configure Crown Port+" on page 125.*

9 In the **Printer Ports** dialog box, click Close.

10 In the Properties dialog box for the printer, click Close.

*For Windows NT 4.0, click **OK**.*

For Windows Me and 98 SE:

1 Click **Start**, point to Settings, and then click **Printer**.

2 Right-click the printer icon, and then click **Properties**.

*The **Properties** dialog box for the printer appears.*

3 Click the **Details** tab.

4 Click **Add Port**.

*The **Add Port** dialog box appears.*

5 Select **Other**, and then select **Crown Port+** from the **Click the type of port you want to add** list.

6 Click **OK**.

*The **Add Crown Port+** dialog box appears.*



7 In the **IP Address** text box, type the IP address for the printer.

For this address, type in a unique host name or the dot notation identifier (IP address) for the printer.

The printer search function is not supported with this printer.

8 In the **Port Name** text box, type the logical name of the port.

The logical name of the port is the description identifier for the port. Each port name must be unique.

A maximum of 128 characters can be entered for the port name.

*If nothing is entered in the **IP Address** text box, the text entered in the **Port Name** text box is added to the **IP Address** text box. Change the text as necessary.*

9 Click **OK**.

*Click **Advanced** to display the **Configure Crown Port+** dialog box, and then specify the advanced settings for the Crown port. For details, refer to "Configure Crown Port+" on page 125.*

10 In the **Properties** dialog box for the printer, click **OK**.

Configure Crown Port+

In the **Configure Crown Port+** dialog box, specify the advanced settings for the Crown port.



Parameter	Default Setting	Description
Status update interval	5 seconds	Specify the interval that Crown Print Monitor+ updates the print manager with the status of the printer connected to this port.
Status request timeout	10 seconds	Specify the length of time to wait for an answer from the printer until Crown Print Monitor+ notifies the print manager that there is no response from the printer.

Parameter	Default Setting	Description
Send request timeout	60 minutes	Specify the length of time to wait for the print job to be sent until Crown Print Monitor+ returns the command to the Microsoft Print Spooler. *If the job has been sent through a Windows 2000/NT4 server and the time specified with the timer is exceeded, the print job is automatically stopped and deleted from the system.* *If the job has been sent through a workstation and the time specified with the timer is exceeded, the Windows XP/2000/NT4 Print Spooler appears and displays a message, requesting confirmation to attempt answering again or to cancel the operation. Whether or not there is an answer, the print job is stopped and deleted from the system.*
Port Settings	9100	Select **9100**. *Port 35 is not supported by this printer.*

8 Using PageScope Web Connection

About PageScope Web Connection

This chapter provides information on PageScope Web Connection, an HTTP (HyperText Transfer Protocol)-based web page that resides in your printer and that you can access using your Web browser.

This page gives you instant access to printer status and the most frequently used printer configuration options. Anyone on your network can access the printer using their web browser software. In addition, with the proper password, you can change the configuration of the printer without leaving your PC.



Users who are not given passwords by the administrator can still view the configuration settings and options but are not able to save or apply changes.

Display Language

The language used in the PageScope Web Connection screens is specified from the printer's control panel. For details on specifying the display language, refer to the User's Guide (CD-ROM) provided with the printer.

In addition, the language can be selected from the **Language** drop-down list in PageScope Web Connection.

Requirements

To use PageScope Web Connection, the following is required:

- Windows Server 2003/XP/2000/Me/98SE/NT4.0, Mac OS 9/X 10.2 and later, Linux
- Microsoft Internet Explorer version 5.5 or later
  Netscape Navigator version 7.1 or later

  You do not need an Internet connection.
- TCP/IP communication software (used by PageScope Web Connection) installed on your PC
- A network, to which both your PC and the printer are connected

You cannot access PageScope Web Connection using a local (USB or Parallel) connection. If your PC and printer are connected via a USB cable, use the Status Display.

Setting Up the Printer Web Page

Setting up the printer web page to run on your network involves two basic steps:

- Determining the name or address of your printer
- Setting up the “no proxy” preferences in your browser software

Determining the Printer Name

The printer web page can be accessed in two ways:

The printer names can also be determined via WINS if the network supports it.

- Through the assigned name of the printer—This name comes from the IP host table (the filename is **hosts**) on the computer system and is usually assigned by the system administrator (for example, magicolor 5450). It may be more convenient for you to use the printer name than the IP address.

  Location of the Host Table on the PC

  - Windows Server 2003/XP \windows\system32\drivers\etc\hosts
  - Windows Me/98SE \windows\hosts
  - Windows 2000/NT4.0 \winnt\system32\drivers\etc\hosts

- Through the printer’s IP address—The IP address of your printer is a unique number and, therefore, may be the preferred identification to enter, especially if you have more printers active in your network. The printer’s IP address is listed on the configuration page.

  Location of the Configuration Page in the Printer’s Configuration Menu

  - `PRINT MENU - CONFIGURATION PG` menu

Setting Up Your Browser Software

Since your printer resides on your intranet and is not accessible beyond the firewall of your network, you must set up the proper “preferences” in your browser software. Your printer name or IP address must be added to the “no proxy” list in the preferences dialog box of the browser.

You need to do this procedure only once.

The sample screens below may be different from yours depending on software versions and operating systems in use.

Our examples represent the IP address of the printer with: xxx.xxx.xxx.xxx. Always enter your printer's IP address without leading zeros. For example, 192.168.001.002 should be entered as 192.168.1.2.

Internet Explorer (version 6.0 for Windows)

1 Start Internet Explorer.

2 From the **Tools** menu choose **Internet Options**.

3 Select the **Connections** tab on the dialog box.

4 Choose the **LAN Settings** button to display the Local Area Network (LAN) Settings dialog box.

5 Select **Advanced** in Proxy server to open the Proxy Settings dialog box.

6 In the **Exceptions** text box, type a comma after the last entry and then type the printer name or the IP address of your printer.



7 Choose **OK** three times to return to the main browser window.

8 Enter the printer's IP address in the URL Address box to access the printer home page.

Netscape Navigator (version 7.1)

1 Start Netscape Navigator.

2 From the **Edit** menu choose **Preferences**.

3 Select the Advanced/Proxies directory from the left pane of the dialog box.

4 Select the **Manual Proxy Configuration** radio button.

5 In the **No Proxy for**: text box, type a comma after the last entry, and then type the printer name or the IP address of your printer.



6 Choose **OK** to return to the main browser window.

7 Enter the printer name or IP address in the URL Location box to access the printer home page.



Understanding the PageScope Web Connection Window

The illustration below identifies the navigation and configuration areas of the windows that you see in PageScope Web Connection windows.



Navigation

Selecting the main topic and subtopic displays the configuration area for the printer options (parameters) associated with your selections.

To change a current setting, click on the current setting and then select from the available choices or enter the new value.

In order to apply or save any changes made to the configuration settings, PageScope Web Connection must be logged in from Administrator Mode. (For details, refer to "Administrator Mode" on page 134.)

Current Status

The current status of the printer is displayed at the top of all PageScope Web Connection windows. The icon displays the type of status being displayed.

Icon	Status	Description	Examples
	Ready	The printer is online and either ready to print or printing.	READY WARMING UP PRINTING
	Warning	The printer needs attention, but printing continues.	PAPER EMPTY TRAY 1 TONER LOW C
	Error	The printer needs attention before printing can resume.	TONER EMPTY REPLACE C PAPER JAM TRAY2
	Fatal	The printer must be rebooted. If that doesn't fix the error, service is required.	SERVICE CALL C002 RAM ERROR

User Mode

You automatically enter User Mode whenever you enter PageScope Web Connection. In User Mode you can view configuration settings but not change them.

Administrator Mode

In order to change any configuration settings through PageScope Web Connection, you must first enter Administrator Mode:

1 Choose the **Login** button.

2 Type the password in the **Admin Password** text box.

*There is no default password specified; however, once you have logged on in Administrator Mode, the password can be specified in the **System/Password** window.*

3 Choose the **Login** button.

If you type an incorrect password, the following message displays: "Invalid Password Please check your input and try again !" Retype the password.

Viewing Printer Status

System Page

The System page is the starting point for all access to the printer's internal web pages. On this page you find printer status and current configuration settings, printer identification, and links to all other web pages.



All of the information displayed on the System page is read only.

Summary (shown above)

The **System - Summary** window provides the following information.

Item	Description
Printer name/status	Shows the name assigned to your printer, and displays the current status of the printer—just as it's displayed on the printer's control panel message window. *The status display allows you to remotely identify possible printer problems, such as out of paper and out of toner.*
Device Status (Product image)	Identifies the type of printer that you are browsing. The printer is pictured in the illustration with all installed options.
Memory	Displays the amount of memory installed in the printer.
HDD	If an optional Hard Disk is installed in the printer, displays the size of the Hard Disk. If no optional Hard Disk is installed in the printer, displays 0 MBytes.
Duplex	Identifies whether the duplex option is "Installed" or "Not Installed."
Network	Lists the installed printer interface (Ethernet 10 BaseT/100Base TX/1000Base-T).
Paper Source	Identifies the paper feed units installed on the printer.
Output Tray	Identifies the output trays installed on the printer.

Device Information



The **System - Device Information** window provides the following information.

Item	Description
System Version	Identifies the controller firmware version.
Control Panel Language	Identifies the display language for the printer control panel.
Country	Identifies the country specifications of the printer.
Administrator Name	Identifies the name of the administrator of the printer.

Detail

Paper Source



The **System - Detail - Paper Source** window provides the following information.

Item	Description
Paper Source	Identifies the paper feed units Tray 1/2/3/4 installed on the printer.
Paper Size	Indicates the size of paper loaded in a specific tray.
Paper Type	Indicates the type of paper loaded in a specific tray.
Paper	Indicates the paper status (“Ready” or “Empty”) for each tray.
Detail button	Displays detailed information about the paper trays.

Paper Source (Detail)



The **System - Detail - Paper Source - Detail** window provides the following information.

Item	Description
Paper Source	Displays the names of the paper trays.
Paper Size	Displays the paper sizes.
Paper Type	Displays the paper types.
Capacity	Displays the maximum capacity for each paper tray.
Paper	Displays the amount of paper remaining.
Back button	Returns to the previous screen.

Output Tray



The **System - Detail - Output Tray** window provides the following information.

Item	Description
Tray	Displays the names of the output trays.
Paper	Displays the status (Ready, Full) of the output trays.

Hard Disk



The **System - Detail - Hard Disk** window provides the following information.

Item	Description
Total	Displays the total amount of space on the hard disk. If no hard disk drive is installed, "-" is displayed.
Used	Displays the amount of space on the hard disk that is used. If no hard disk drive is installed, "-" is displayed.
Remaining	Displays the amount of space remaining on the hard disk. If no hard disk drive is installed, "-" is displayed.

Interface Information

The **System - Detail - Interface Information** window provides the following information.

Item		Description
Protocol Information	TCP/IP	If **Enable** is displayed, TCP/IP is enabled. If **Disable** is selected, TCP/IP is disabled.
	IPP	If **Enable** is displayed, IPP is enabled. If **Disable** is selected, IPP is disabled.
	NetWare	If **Enable** is displayed, NetWare is enabled. If **Disable** is selected, NetWare is disabled.

Item		Description
	AppleTalk	If **Enable** is displayed, AppleTalk is enabled. If **Disable** is selected, AppleTalk is disabled.
	SMTP	If **Enable** is displayed, SMTP is enabled. If **Disable** is selected, SMTP is disabled.
	SNMP	If **Enable** is displayed, SNMP is enabled. If **Disabled** is selected, SNMP is diabled.
	FTP	If **Enable** is displayed, FTP is enabled. If **Disable** is selected, FTP is disabled.
	SMB	If **Enable** is displayed, SMB is enabled. If **Disable** is selected, SMB is disabled.
	Bonjour	If **Enable** is displayed, Bonjour is enabled. If **Disable** is displayed, Bonjour is disabled.
Network Information	Type	Identifies the type of network interface installed on the printer (Ethernet 10Base-T/100Base-TX/1000Base-T).
	Ethernet Speed	Indicates the transmission speed for the network and the transmission method for bi-directional transmission.
	IP Address	Identifies the IP (Internet Protocol) address of the Ethernet interface.
	MAC Address	Identifies the Media Access Control (MAC) address of the Ethernet interface.
	Host Name	Identifies the host name for the printer.
	Print Server Name (NetWare)	Identifies the Print Server Name for the NetWare.
	WorkGroup Name (Windows)	Identifies the domain or the workgroup name for the printer.
	Printer Name (Apple Talk)	Identifies the printer name on AppleTalk.
	Current Zone Name (AppleTalk)	Identifies the Current Zone Name for the AppleTalk.
	Bonjour Name	Displays the Bonjour name for the printer.

Consumables



The **System - Details - Consumables** window provides the following information:

Item	Description
Type	Identifies the type of consumable that is being monitored.
Status	Indicates the remaining life of the consumables. ■ Toner Cartridge, Transfer Belt, Transfer Unit, Fuser Unit: Percentage ■ Waste Toner Bottle: Ready, Near Full, or Full
Type	Indicates the type of consumables ■ Starter, Standard, High

Counter



The **System - Counter** window provides the following information:

Item	Description
Total Counter	Indicates the number of prints.
Detail Counter	Indicates the number of prints (the total amount and double-sided prints).

Online Assistance



The **System - Online Assistance** window provides the following information:

Item	Description
Contact	Displays the organization that provides assistance with the printer.
Contact Information	Displays the web address for assistance.
Product Help URL	Displays the web address for assistance.
Corporate URL	Displays the KONICA MINOLTA web address.
Supplies and Accessories	Displays the web address where you can order printer supplies and accessories.
Contact Phone Number	Displays the telephone number of the printer administrator.
Contact Address	Displays the e-mail address for support.
Contact Utility Link	Displays a link to the Printer Management Utilities.

Job Page

This page allows you to view the status of current print jobs.



Active Job List (shown above)

The **Job - Active Job List** window provides the following information for up to 49 print jobs:

Item	Description
Job Number	Displays the print job identification number. Each print job that the printer receives is assigned a unique identification number.
User Name	If known, displays the owner of the print job.
Job Status	Displays the current status of the print job (Parsing, Printing, Cancel, or Abort).
File Name	Displays the name of the print file.
Create Time	Displays the time that the job was queued.
Delete button	Deletes the print job(s) whose check boxes in column 1 are checked.

Done Job List



The **Job - Done Job List** window provides the following information for up to 49 print jobs:

Item	Description
Job Number	Displays the print job identification number. Each print job that the printer receives is assigned a Number unique identification number.
User Name	If known, displays the owner of the print job.
File Name	Displays the name of the print file.
End Time	Displays the time that printing finished.
Result	Displays the result of the print job (OK, Error, or Canceled).
Detail button	Displays a screen containing details.

Done Job List (Detail)



The **Job - Done Job List - Detail** window provides the following information for the selected job:

Item	Description
Job Number	Displays the print job identification number. Each print job that the printer receives is assigned a Number unique identification number.
User Name	If known, displays the owner of the print job.
File Name	Displays the name of the print file.
Delivery Type	Displays the delivery method for the job.
Create Time	Displays the time that the job was queued.
End Time	Displays the time that printing finished.
Result	Displays the result of the print job (OK, Error, or Canceled).
Back button	Returns to the previous screen.

Print Page

This page allows you to check the settings for printing when there is no PDL printer driver.



Default Settings

General Settings (shown above)

The **Print - Default Settings - General Settings** window provides the following information.

Item	Description
PDL	Indicates default language to be selected.
Paper Source	The paper tray that is normally used is indicated.
Duplex	If **Off** is indicated, duplex printing is not possible. If **Long-Edge Binding** is indicated, the pages will be printed on both sides of the paper for long-edge binding. If **Short-Edge Binding** is indicated, the pages will be printed on both sides of the paper for short-edge binding. This menu item appears only if the optional duplex unit is installed.
Output Tray	Displays the name of the output tray.

Item	Description
Copies	Indicates the default setting for number of copies to be printed.
Paper Size	Indicates the default setting for the size of paper.
X Dimension	Indicates the paper width when Paper Size is set to CUSTOM.
Y Dimension	Indicates the paper length when Paper Size is set to CUSTOM.
Paper Type	Indicates the default setting for the type of paper.
Collate	If **On** is indicated, all pages in a copy of the document can be printed before printing the next copy. If **Off** is indicated, all copies of the document are not printed separately. This menu item appears only if the optional hard disk drive is installed.
Unit of Measure	The units for specifying the size of custom paper is indicated between inches and millimeters.

Paper Source Settings



The **Print - Default Settings - Paper Source Settings** window provides the following information.

Item		Description
Tray1	Paper Size	Indicates the setting for the size of paper loaded into Tray 1.
	Paper Type	Indicates the setting for the type of paper loaded into Tray 1.
Tray2	Paper Size	Indicates the setting for the size of paper loaded into Tray 2.
	Paper Type	Indicates the setting for the type of paper loaded into Tray 2.
Tray3 This item appears only if the optional lower feeder unit is installed.	Paper Size	Indicates the setting for the size of paper loaded into Tray 3.
	Paper Type	Indicates the setting for the type of paper loaded into Tray 3.

Item		Description
Tray4 This item appears only if the optional lower feeder unit is installed.	Paper Size	Indicates the setting for the size of paper loaded into Tray 4.
	Paper Type	Indicates the setting for the type of paper loaded into Tray 4.
Tray Chaining		If **ON** is indicated and the specified paper tray runs out of paper during printing, a paper tray loaded with paper of the same size is automatically selected so printing can continue. If **OFF** is indicated and the specified paper tray runs out of paper, printing stops.
Tray Mapping	Tray Mapping Mode	If **On** is indicated, Tray Mapping function is used. If **Off** is indicated, Tray Mapping function is not used.
	Logical Tray 0-9	Indicates the tray that is used for printing when a print job is received from another manufacturer's printer driver.

PCL Settings



The **Print - Default Settings - PCL Settings** window provides the following information.

Item	Description
Font Number	Displays the default font in the PCL language.
Symbol Set	Displays the symbol set used with the PCL language.
Lines Per Page	Indicates how many lines are in a page in PCL language.
Font Point Size	Displays the font size in the PCL language.
Font Pitch Size	Displays the font pitch in the PCL language.
CR/LF Mapping	Indicates CR/LF code definition in PCL language.

PS Settings



The **Print - Default Settings - PS Settings** window provides the following information.

Item	Description
Wait Timeout	Indicates Postscript timeout. “0” means that no time-out control is effective.
PS Protocol	Displays the settings for the PS protocol.
Print to PS Error	Displays whether or not error printing is performed.

Print Quality Settings



The **Print - Default Settings - Print Quality Settings** window provides the following information.

Item		Description
Print Quality Settings	Color Mode	If **Color** is indicated, the pages are printed in full color. If **Grayscale** is indicated, the pages are printed in black and white.
	Color Separation	If **On** is indicated, color separation is performed. If **Off** is indicated, color separation is not performed.
	Brightness	Indicates the brightness of the printed image.
	Contrast (PCL Only)	Indicates the contrast of the image.

Item		Description
Color Matching Setting	Simulation Profile (PS Only)	Indicates the specific ICC simulation profile to be used for printed output.
	Simulation Intent (PS Only)	Indicates the simulation intent to be used for simulation printing.
	CMYK Gray Treatment	Indicates the method to reproduce CMYK black and gray for simulation printing.
	Destination Profile	Indicates the ICC destination profile to be used for printed output.
Image Printing	RGB Source	Identifies the color space for RGB image data.
	RGB Intent	Indicates the color intent to be used on conversion RGB to CMYK by printer for images.
	RGB Gray Treatment	Indicates the method to reproduce RGB black and gray of images.
	Halftone	Indicates how halftones are reproduced. If **Line Art** is indicated, halftones are reproduced with high precision. If **Detail** is indicated, halftones are reproduced with detail. If **Smooth** is indicated, halftones are reproduced with smoothness.
Text Printing	RGB Source	Identifies the color space for RGB text data.
	RGB Intent	Indicates the color intent to be used on conversion RGB to CMYK by printer for texts.
	RGB Gray Treatment	Indicates the method to reproduce RGB black and gray of texts.
	Halftone	Indicates how halftones are reproduced. If **Line Art** is indicated, halftones are reproduced with high precision. If **Detail** is indicated, halftones are reproduced with detail. If **Smooth** is indicated, halftones are reproduced with smoothness.

Item		Description
Graphics Printing		Indicates the color settings for graphics.
Calibration	Tone Calibration	If On is indicated, image adjustments are applied. If Off is indicated, image adjustments are not applied.

Camera Direct Print Settings



The **Print - Default Settings - Camera Direct Settings** window provides the following information.

Item	Description
Camera Direct Print	If **Enable** is indicated, camera direct printing is enabled. If **Disable** is indicated, camera direct printing is disabled.
Paper Source	Indicates the tray that is used for camera direct printing.
Layout	Indicates the number of images printed on a single sheet of media. If **1-up** is indicated, only one image will be printed on a single sheet of media.
Paper Margin	Indicates the size of the media margins (area that is not printed in). If **Standard** is indicated, the standard media margin size is specified. If **Minimum** is indicated, the media margins are reduced.

Item	Description
Brightness	Indicates the brightness of the printed image.
Contrast	Indicates the contrast of the image.
RGB Source	Indicates the color space for RGB image data. If **Device Color** is indicated, the device profile of this printer is used.
RGB Intent	Indicates the characteristic applied when converting RGB image data to CMYK data. If **Vivid** is indicated, a vivid output is produced. If **Photographic** is indicated, a brighter output is produced.
RGB Gray Treatment	Indicates how black and grays are reproduced in RGB image data. If **Composite Black** is indicated, black is reproduced using the CMYK colors. If **Black And Gray** is indicated, black and gray are reproduced using black only. If **Black Only** is indicated, black is reproduced using only black.
Halftone	Indicates how halftones are reproduced. If **Line Art** is indicated, halftones are reproduced with high precision. If **Detail** is indicated, halftones are reproduced with detail. If **Smooth** is indicated, halftones are reproduced with smoothness.

Download Font/Form

PCL Font



The **Print - Download Font/Form - PCL Font** page allows you to check the list of PCL fonts that the printer manages.

Item	Description
Number	Displays the control number of the font.
Font Name	Displays the name of the fonts.

PS Font



The **Print - Download Font/Form - PS Font** page allows you to check the list of PostScript fonts that the printer manages.

Item	Description
Number	Displays the control number of the font.
Font Name	Displays the name of the fonts.

Form Overlay



The **Print - Download Font/Form - Form Overlay** page allows you to check the list of form overlays that the printer manages.

Item	Description
Number	Displays the control number of the overlay.
File Name	Displays the name of the overlays.

Color Profile


http://192.168.1.193/ - Microsoft Internet Explorer
File Edit View Favorites Tools Help
KONICA MINOLTA
Web Connection
Ready
READY
KONICA MINOLTA
magicolor 5450
Log in
Language
English
System
Job
Print
Default Settings
Download Font/Form
PCL Font
PS Font
Form Overlay
Color Profile
Report Types
Direct Print
Color Profile
Number | File Name | Profile Name | Class | Color Space | Available
1 | | sRGB | Display Device | RGB | Yes
2 | | AppleRGB | Display Device | RGB | Yes
3 | | AdobeRGB1998 | Display Device | RGB | Yes
4 | | ColorMatchRGB | Display Device | RGB | Yes
5 | | BlueAdjustRGB | Input Device | RGB | Yes
6 | | SWOP | Output Device | CMYK | Yes
7 | | Eurocolor | Output Device | CMYK | Yes
8 | | Commercial | Output Device | CMYK | Yes
9 | | TOYO | Output Device | CMYK | Yes
10 | | DIC | Output Device | CMYK | Yes
Done
Local intranet

The **Print - Download Font/Form - Color Profile** page allows you to check the list of color profiles that the printer manages.

Item	Description
Number	Displays the control number of the color profile.
File Name	Displays the file name of the color profile.
Profile Name	Displays the name of the color profile.
Class	Displays the type of color profile.
Color Space	Displays the color space for the color profile.
Available	Indicates whether or not the color profile can be used.

Report Types



The **Print - Report Types** window provides the following information.

Item	Description
Configuration Page	Prints the printer configuration page.
Demo Page	Prints the printer demo page.
Statistics Page	Prints the statistics page such as the number of pages printed.
PCL Font Page	Prints the PCL font lists.
PS Font Page	Prints the PostScript font lists.
Menu Map Page	Prints the menu map.
Directory Listing Page	Prints the directory list. This item appears only if an optional hard disk is installed.
Print button	Sends the page to the printer.
Clear button	Cancels the selected settings.

Direct Print



The **Print - Direct Print** page allows you to print a file directly from the printer without starting up the application.

The printer must have the optional hard disk to use the Direct Print parameters described below.
The following file formats can be printed using direct printing: PDF, TIF and JPEG.

Item	Description
File Name	Specify the location of the file to be printed. Click **Browse**, and then select the file.
Browse button	Displays a dialog box for browsing to the file to be printed.
Send button	Sends the specified file to the printer.

Configuring the Printer

In order to make any configuration changes through PageScope Web Connection, you must first enter Administrator Mode. See “Administrator Mode” on page 134 for instructions on logging into Administrator Mode.

System Page

This page allows you to configure several user- and printer-specific items.



Date/Time

Manual Settings (shown above)

The **System - Date/Time - Manual Settings** window allows you to configure the following items:

Item	Description
Year	Specifies the year for the printer’s internal clock. Configuration Menu Equivalent: `SYS DEFAULT MENU - CLOCK - DATE`
Month	Specifies the month for the printer’s internal clock. Configuration Menu Equivalent: `SYS DEFAULT MENU - CLOCK - DATE`

Item	Description
Day	Specifies the day for the printer's internal clock. Configuration Menu Equivalent: `SYS DEFAULT MENU - CLOCK - DATE`
Hour	Specifies the hour for the printer's internal clock. Configuration Menu Equivalent: `SYS DEFAULT MENU - CLOCK - TIME`
Minute	Specifies the minute for the printer's internal clock. Configuration Menu Equivalent: `SYS DEFAULT MENU - CLOCK - TIME`
Time Zone	Specifies the time zone for sending e-mail notifications.
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Admin Password



The **System - Admin Password** window allows you to configure the following items:

Item	Description
Current Password	Type in the current password. Range: Up to 16 characters Default: [Blank]
New Password	Sets a new password to enter Administrator Mode. Range: Up to 16 characters Default: [Blank] *Passwords can be set to any string of numbers and letters (uppercase and lowercase) up to 16 characters in length.*

Item	Description
Retype Password	Verifies the new password typed in the **New Password** text box. Range: Up to 16 characters Default: [Blank] *If the password typed in three text boxes doesn't match, the following message displays when you choose the **Apply** button: "Please retype the correct password." Click **OK** button, and then retype the passwords in both text boxes.*
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

If you forget the new password you've assigned, use the printer's `SYS DEFAULT MENU/RESTORE DEFAULTS/RESTORE NETWORK` *menu to reset the password (and all other network configuration choices) to administrator.*

Device Information



The **System - Device Information** window allows you to configure the following items:

Item	Description
Administrator Name	Specifies the name of the administrator for the printer. Range: Up to 255 characters Default: [Blank]
Device Name	Specifies the name of the printer. Range: Up to 255 characters Default: [Blank]
Device Place	Specifies the setup location for the printer. Range: Up to 255 characters Default: [Blank]

Item	Description
Do Startup Page	Selects whether or not a startup page is printed when the printer is turned on. Choices: On, Off Default: Off Configuration Menu Equivalent: `SYS DEFAULT MENU - STARTUP OPTIONS - DO STARTUP PAGE`
Auto Continue	Selects whether or not printing continues if the size or type of paper in the selected paper tray is different from the size or type of paper for the print job. Choices: On, Off Default: Off Configuration Menu Equivalent: `SYS DEFAULT - AUTO CONTINUE`
Hold Job Timeout	Specifies the length of time until print jobs saved on the hard disk are deleted. If Disable is selected, print jobs are not deleted at a specific time. Choices: Disabled, One Hour, Four Hours, One Day, One Week Default: Disabled Configuration Menu Equivalent: `SYS DEFAULT MENU - HELD JOB TIME OUT` This menu item appears only if the optional hard disk drive is installed.
Energy Saver	If On is selected, the machine will enter Energy Saver mode. If Off is selected, the machine will not enter Energy Saver mode. Choices: On, Off Default: On Configuration Menu Equivalent: `SYS DEFAULT MENU - ENERGY SAVER`

Item	Description
Energy Saver Time	Specifies the length of time until the machine enters Energy Saver mode. This menu item appears only when Energy Saver is set to On. Choices: 5 minutes, 15 minutes, 30 minutes, 1 Hours, 3 Hours Default: 30 minutes Configuration Menu Equivalent: `SYS DEFAULT MENU - ENERGY SAVER TIME`
Menu Timeout	Specifies the length of time until the status screen is displayed when no operation is performed while a menu or help screen is displayed in the message window. If Off is selected, no timeout occurs. Choices: Off, 1 minute, 2 minutes Default: 2 minutes Configuration Menu Equivalent: `SYS DEFAULT MENU - TIME OUT`
Toner Empty	If Stop is selected, printing stops when the toner runs out. If Continue is selected, printing continues even if toner runs out. Choices: Stop, Continue Default: Stop Configuration Menu Equivalent: `SYS DEFAULT MENU - TONER EMPTY`
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

ROM Version



The **System - ROM Version** window provides the following information.

Item	Description
Engine ROM Version	Displays the ROM version of the printer engine.
Controller ROM Version	Displays the ROM version of the printer controller.
Boot ROM Version	Displays the ROM version of the Boot ROM.

Online Assistance



The **System - Online Assistance** window allows you to configure the following items:

Item	Description
Contact Name	Sets the name of the person or organization responsible for providing assistance with the printer. Range: Up to 63 characters Default: [Blank]
Contact Information	Sets the telephone number for printer assistance. Range: Up to 127 characters Default: [Blank]
Product Help URL	Sets the help web site address for printer assistance. Range: Up to 127 characters Default: [Blank]
Corporate URL	Sets the KONICA MINOLTA corporate web site address. Range: Up to 127 characters Default: [Blank]

Item	Description
Supplies and Accessories	Sets the web address where you can purchase printer supplies and accessories. Range: Up to 127 characters Default: [Blank]
Contact Phone Number	Specifies the telephone number of the printer administrator. Range: Up to 31 characters Default: [Blank]
Contact Address	Specifies the address of the printer administrator. Range: Up to 320 characters Default: [Blank]
Contact Utility Link	Specifies the link to the Printer Management Utilities. Range: Up to 127 characters Default: [Blank]
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Maintenance

Clear Settings



The **System - Maintenance - Clear Settings** page allows you to reset the printer settings to its factory defaults.

Item	Description
Printer Settings	Resets the printer settings to their defaults. Configuration Menu Equivalent: `SYS DEFAULT MENU - RESTORE DEFAULTS - RESTORE PRINTER`
Network Settings	Resets the network settings to their defaults. Configuration Menu Equivalent: `SYS DEFAULT MENU - RESTORE DEFAULTS - RESTORE NETWORK`
All Settings	Resets all settings to their defaults. Configuration Menu Equivalent: `SYS DEFAULT MENU - RESTORE DEFAULTS - RESTORE ALL`
Clear button	When clicked, the message “Is it OK to restore Factory Defaults?” appears. Click **OK** to automatically restart the printer and return the settings to their default values.

Item	Description
Logout button	Logs out of Administrator Mode and returns to User Mode.

Reset Printer



The **System - Maintenance - Reset Printer** page allows you to reset the printer controller.

Item	Description
Reset button	When clicked, the message “Is it OK to reset the Printer?” appears. Click **OK** to automatically restart the printer.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Alert Mail



The **System - Alert Mail** window allows you to configure the following items:

Item		**Description**
Alert Mail	Email Notice	Specifies whether or not a notification is sent by e-mail when a warning occurs in the printer. Choices: Enable, Disable Default: Enable
	Email Address Notice	Specifies the e-mail address where the notification is sent. Range: Up to 320 characters Default: [Blank]

Item		Description
Alert	Paper Empty	Specifies whether or not a notification is sent when the paper tray runs out of paper. Choices: Enable, Disable Default: Enable
	Paper Jam	Specifies whether or not a notification is sent when a paper misfeed occurs. Choices: Enable, Disable Default: Enable
	Maintenance	Specifies whether or not a notification is sent when the time for a periodic maintenance has been reached. Choices: Enable, Disable Default: Enable
	Toner Empty	Specifies whether or not a notification is sent when the toner is empty. Choices: Enable, Disable Default: Enable
	Operator Call	Specifies whether or not a notification is sent when the operator must be called. Choices: Enable, Disable Default: Enable
	Service Call	Selects whether or not notification is sent to the service representative when a condition occurs that requires servicing. Choices: Enable, Disable Default: Enable
	Job Complete	Specifies whether or not a notification is sent when a print job is completed correctly. Choices: Enable, Disable Default: Enable
	Job Error	Specifies whether or not a notification is sent when a job could not be printed because an error occurred. Choices: Enable, Disable Default: Enable

Item	Description
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Print

The **Print** page allows more detailed printer settings to be specified.

Local Interface



The **Print - Local Interface** window allows you to configure the following items:

Item	Description
I/O Timeout	Specifies the reception timeout (in seconds). Range: 5-300 Default: 15
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Default Settings

General Settings



The **Print - Local Interface** window allows you to configure the following items:

Item	Description
PDL	Selects default language to be selected. Choices: Auto, PCL, PS Default: Auto Configuration Menu Equivalent: `SYS DEFAULT MENU - EMULATION - DEF. EMULATION`
Paper Source	The paper tray that is normally used can be specified. Choices: Tray1, Tray2, Tray3, Tray4 Configuration Menu Equivalent: `PAPER MENU - INPUT TRAY - DEFAULT TRAY`

Item	Description
Duplex	If **Off** is selected, duplex printing is not possible. If **Long-Edge Binding** is selected, the pages will be printed on both sides of the paper for long-edge binding. If **Short-Edge Binding** is selected, the pages will be printed on both sides of the paper for short-edge binding. Choices: Off, Short-Edge Binding, Long-Edge Binding Default: Off Configuration Menu Equivalent: `PAPER MENU - DUPLEX` This menu item appears only if the optional duplex unit is installed.
Output Tray	Displays the name of the output tray.
Copies	Specifies the default setting for number of copies to be printed. Range: 1-9999 Default: 1 Configuration Menu Equivalent: `PAPER MENU - COPIES`
Paper Size	Specifies the default setting for the size of paper.
Width	Specifies the paper width when Paper Size is set to Custom. Range: 3.65 - 8.50 (inch) / 92 - 216 (mm)
Length	Specifies the paper length when PAPER SIZE is set to Custom. Range: 5.85 - 14.00 (inch) / 148 - 356 (mm)
Paper Type	Specifies the default setting for the type of paper. Choices: Plain Paper, Recycled, Thick 1, Thick 2, Label, Transparency, Envelope, Postcard, Letterhead, Glossy Default: Plain Paper

Item	Description
Collate	If **On** is selected, all pages in a copy of the document can be printed before printing the next copy. If **Off** is selected, all copies of the document are not printed separately. Choices: On, Off Default: Off Configuration Menu Equivalent: PAPER MENU - COLLATE This menu item appears only if the optional hard disk drive is installed.
Unit of Measure	The unit for specifying the size of custom paper can be specified between inches and millimeters. Choices: Inches, Millimeters Configuration Menu Equivalent: PAPER MENU - UNIT OF MEASURE
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Paper Source Settings



The **Print - Paper Source Settings** window allows you to configure the following items:

Item		Description
Tray1	Paper Size	Specifies the setting for the size of paper loaded into Tray 1. Default: Letter (U.S. model) A4 (Other model) Configuration Menu Equivalent: `PAPER MENU - PAPER SOURCE - TRAY1 - PAPER SIZE`
	Width	Specifies the paper width when Paper Size is set to Custom. Range: 3.65 - 8.50 (inch) / 92 - 216 (mm) Configuration Menu Equivalent: `PAPER MENU - PAPER SOURCE - TRAY1 - CUSTOM SIZE`

Item		Description
	Length	Specifies the paper length when Paper Size is set to Custom. Range: 5.85 - 14.00 (inch) / 148 - 356 (mm) Configuration Menu Equivalent: PAPER MENU - PAPER SOURCE - TRAY1 - CUSTOM SIZE
	Paper Type	Specifies the setting for the type of paper loaded into Tray 1. Default: Any, Plain Paper, Recycled, Thick 1, Thick2, Label, Transparency, Envelope, Postcard, Letterhead, Glossy Configuration Menu Equivalent: PAPER MENU - PAPER SOURCE - TRAY1 - PAPER TYPE
Tray2	Paper Size	Specifies the setting for the size of paper loaded into Tray 2. Default: Letter (U.S. model) A4 (other model) Configuration Menu Equivalent: PAPER MENU - PAPER SOURCE - TRAY2 - PAPER SIZE
	Paper Type	Specifies the setting for the type of paper loaded into Tray 2. Default: Any, Plain Paper, Rycycled Configuration Menu Equivalent: PAPER MENU - PAPER SOURCE - TRAY2 - PAPER TYPE

Item		Description
Tray3 This item appears only if the optional lower feeder unit is installed.	Paper Size	Displays the setting for the size of paper loaded into Tray 3.
	Paper Type	Specifies the setting for the type of paper loaded into Tray 3. Default: Any, Plain Paper, Rycycled Configuration Menu Equivalent: `PAPER MENU - PAPER SOURCE - TRAY3 - PAPER TYPE`
Tray4 This item appears only if the optional lower feeder unit is installed.	Paper Size	Displays the setting for the size of paper loaded into Tray 4. Configuration Menu Equivalent: `PAPER MENU - PAPER SOURCE - TRAY4 - PAPER SIZE`
	Paper Type	Specifies the setting for the type of paper loaded into Tray 4. Default: Any, Plain Paper, Rycycled Configuration Menu Equivalent: `PAPER MENU - PAPER SOURCE - TRAY4 - PAPER TYPE`
Tray Chaining	Tray Chaining	If **Enable** is selected and the specified paper tray runs out of paper during printing, a paper tray loaded with paper of the same size is automatically selected so printing can continue. If **Disable** is selected and the specified paper tray runs out of paper, printing stops. Choices: Enable, Disable Default: Enable Configuration Menu Equivalent: `PAPER MENU - PAPER SOURCE - TRAY CHAINING`

Item		Description
Tray Mapping	Tray Mapping Mode	Select whether or not the Tray Mapping function is used. Choices: On, Off Default: Off Configuration Menu Equivalent: `PAPER MENU - PAPER SOURCE - TRAY MAPPING - TRAY MAPPING MODE`
	Logical Tray 0-9	Select the tray that is used for printing when a print job is received from another manufacturer's printer driver. The default setting for **LogicaL Tray 1** is **Physical Tray1**. The default setting for all other trays is **Physical Tray2**. Choices: Physical Tray1, Physical Tray2, Physical Tray3, Physical Tray4 Configuration Menu Equivalent: `PAPER MENU - PAPER SOURCE - TRAY MAPPING - LOGICAL TRAY0-9` *Physical Tray3 and Physical Tray4 appear only if an optional lower feeder unit is installed.*
Apply button		Applies the configuration settings for this window.
Clear button		Resets all configuration settings to previous values.
Logout button		Logs out of Administrator Mode and returns to User Mode.

PCL Settings



The **Print - PCL Settings** window allows you to configure the following items:

Item	Description
Font Number	Sets the default font in the PCL language. Range: 0 - 102 Default: 0
Symbol Set	Selects the symbol set used with the PCL language. Default: PC-8
Lines Per Page	Selects how many lines are in a page in PCL language. Range: 5 - 128 Default: 60 Configuration Menu Equivalent: `SYS DEFAULT MENU - EMULATION - PCL - LINES PER PAGE`

Item	Description
Font Point Size	Sets the font size in the PCL language. Range: 4.00 - 999.75 Default: 12.00 Configuration Menu Equivalent: `SYS DEFAULT MENU - EMULATION - PCL - FONT SOURCE - POINT SIZE`
Font Pitch Size	Sets the font pitch in the PCL language. Range: 0.44 - 99.99 Default: 10.00 Configuration Menu Equivalent: `SYS DEFAULT MENU - EMULATION - PCL - FONT SOURCE - PITCH SIZE`
CR/LF Mapping	Selects CR/LF code definition in PCL language. Choices: CR=CR LF=LF, CR=CRLF LF=LF, CR=CR LF=LFCR, CR=CRLF LF=LFCR Default: CR=CR LF=LF Configuration Menu Equivalent: `SYS DEFAULT MENU - EMULATION - PCL - FONT SOURCE - CR/LF MAPPING`
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

PS Settings



The **Print - PS Settings** window allows you to configure the following items:

Item	Description
Wait Timeout	Sets Postscript timeout. “0” means that no time-out control is effective. Range: 0 - 300 (in seconds) Default: 0 Configuration Menu Equivalent: `SYS DEFAULT MENU - EMULATION - POSTSCRIPT - WAIT TIME OUT`
PS Protocol	Specifies the PS protocol. Choices: Auto, Normal, Binary Default: Auto Configuration Menu Equivalent: `SYS DEFAULT MENU - EMULATION - POSTSCRIPT - PS PROTOCOL`
Print to PS Error	Specifies whether or not error printing is performed. Choices: On, Off Default: Off Configuration Menu Equivalent: `SYS DEFAULT MENU - EMULATION - POSTSCRIPT - PS ERROR PAGE`
Apply button	Applies the configuration settings for this window.

Item	Description
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Print Quality Settings



The **Print - Print Quality Settings** window allows you to configure the following items:

Item		Description
Print Quality Settings	Color Mode	If **Color** is selected, the pages are printed in full color. If **Monochrome** is selected, the pages are printed in black and white. Choices: Color, Monochrome Default: Color Configuration Menu Equivalent: `QUALITY MENU - PRINT COLOR`

Item		Description
	Color Separation	If **On** is selected, color separation is performed. If **Off** is selected, color separation is not performed. Choices: On, Off Default: Off Configuration Menu Equivalent: `QUALITY MENU - COLOR SEPARATION`
	Brightness	Specifies the brightness of the printed image. Choices: +15%, +10%, +5%, 0, -5%, -10%, -15% Default: 0 Configuration Menu Equivalent: `QUALITY MENU - BRIGHTNESS`
	Contrast (PCL Only)	Specifies the contrast of the image. Choices: +15%, +10%, +5%, 0, -5%, -10%, -15% Default: 0 Configuration Menu Equivalent: `QUALITY MENU - PCL CONTRAST`

Item		Description
PS Profile	Simulation Profile (PS Only)	Specifies the specific ICC simulation profile to be used for printed output. Choices: None, SWOP, Euroscale, CommercialPress, TOYO, DIC Configuration Menu Equivalent: `QUALITY MENU - PS PROFILE - SIMULATION PROF`
	Simulation Intent (PS Only)	Specifies the simulation intent to be used for simulation printing. Choices: Relative Color, Absolute Color Default: Relative Color Configuration Menu Equivalent: `QUALITY MENU - PS PROFILE - SIMULATION INTENT`
	CMYK Gray Treatment	Specifies the method to reproduce CMYK black and gray for simulation printing. Choices: Composite Black, Black and Gray, Black Only Default: Composite Black Configuration Menu Equivalent: `QUALITY MENU - PS PROFILE - CMYK GRAY`
	Destination Profile	Specifies the ICC destination profile to be used for printed output. Default: Auto Configuration Menu Equivalent: `QUALITY MENU - PS PROFILE - DESTINATION PROF`

Item		Description
Image Printing	RGB Source	Specifies the color space for RGB image data. Choice: Device Color, sRGB, AppleRGB, AdobeRGB1998, ColorMatchRGB, BlueAdjustRGB Default: sRGB
	RGB Intent	Specifies the color intent to be used on conversion RGB to CMYK by printer for images. Choices: Vivid, Photographic, Relative Color, Absolute Color Default: Photographic Configuration Menu Equivalent: `QUALITY MENU - IMAGE PRINTING - COLOR MATCHING`
	RGB Gray Treatment	Specifies the method to reproduce RGB black and gray of images. Choices: Composite Black, Black and Gray, Black Only Default: Composite Black Configuration Menu Equivalent: `QUALITY MENU - IMAGE PRINTING - RGB GRAY`

Item		Description
	Halftone	Specifies how halftones are reproduced. If **Line Art** is selected, halftones are reproduced with high precision. If **Detail** is selected, halftones are reproduced with detail. If **Smooth** is selected, halftones are reproduced with smoothness. Choices: Line Art, Detail, Smooth Default: Detail Configuration Menu Equivalent: `QUALITY MENU - IMAGE PRINTING - HALFTONE`

Item		Description
Text Printing	RGB Source	Specifies the color space for RGB text data. Choice: Device Color, sRGB, AppleRGB, AdobeRGB1998, ColorMatchRGB, BlueAdjustRGB Default: sRGB
	RGB Intent	Specifies the color intent to be used on conversion RGB to CMYK by printer for texts. Choices: Vivid, Photographic, Relative Color, Absolute Color Default: Vivid Configuration Menu Equivalent: `QUALITY MENU - TEXT PRINTING - COLOR MATCHING`
	RGB Gray Treatment	Specifies the method to reproduce RGB black and gray of texts. Choices: Composite Black, Black and Gray, Black Only Default: Black and Gray Configuration Menu Equivalent: `QUALITY MENU - TEXT PRINTING - RGB GRAY`

Item		Description
	Halftone	Specifies how halftones are reproduced. If **Line Art** is selected, halftones are reproduced with high precision. If **Detail** is selected, halftones are reproduced with detail. If **Smooth** is selected, halftones are reproduced with smoothness. Choices: Line Art, Detail, Smooth Default: Line Art Configuration Menu Equivalent: `QUALITY MENU - TEXT PRINTING - HALFTONE`
Graphics Printing		Specifies the color settings for graphics. Choices: Same as Image Settings, Same as Text Settings Default: Same as Image Settings Configuration Menu Equivalent: `QUALITY MENU - GRAPHICS PRINTING`
Calibration	Tone Calibration	If ON is selected, image adjustments are applied. If OFF is selected, image adjustments are not applied. Choices: On, Off Default: On Configuration Menu Equivalent: `QUALITY MENU - CALIBRATION`
Apply button		Applies the configuration settings for this window.
Clear button		Resets all configuration settings to previous values.
Logout button		Logs out of Administrator Mode and returns to User Mode.

Camera Direct Print Settings



The **Print - Default Settings - Camera Direct Settings** allows you to configure the following items:

Item	Description
Camera Direct Print	If **Enable** is selected, camera direct printing is enabled. If **Disable** is selected, camera direct printing is disabled. Choices: Enable, Disable Default: Enable
Paper Source	Specifies the tray that is used for camera direct printing. Choices: Tray1, Tray2, Tray3, Tray4 Default: Tray2 Configuration Menu Equivalent: `CAMERA DIRECT - PAPER SOURCE` ***Tray3*** *and* ***Tray4*** *appear only if the optional lower feeder units are installed.*

Item	Description
Layout	Specifies the number of images printed on a single sheet of media. If **1-up** is selected, only one image will be printed on a single sheet of media. Choices: 1-up, 2-up, 3-up, 4-up, 6-up, 8-up Default: 1-up Configuration Menu Equivalent: `CAMERA DIRECT - LAYOUT`
Paper Margin	Specifies the size of the media margins (area that is not printed in). If **Standard** is selected, the standard media margin size is specified. If **Minimum** is selected, the media margins are reduced. Choices: Standard, Minimum Default: Standard Configuration Menu Equivalent: `CAMERA DIRECT - PAPER MARGIN`
Brightness	Specifies the brightness of the printed image. Choices: -15%, -10%, -5%, 0, +5%, +10%, +15% Default: 0 Configuration Menu Equivalent: `CAMERA DIRECT - IMAGE QUALITY - BRIGHTNESS`
Contrast	Specifies the contrast of the image. Choices: -15%, -10%, -5%, 0, +5%, +10%, +15% Default: 0 Configuration Menu Equivalent: `CAMERA DIRECT - IMAGE QUALITY - CONTRAST`
RGB Source	Specifies the color space for RGB image data. If **Device Color** is selected, the device profile of this printer is used. Choices: Device Color, sRGB Default: sRGB Configuration Menu Equivalent: `CAMERA DIRECT - IMAGE QUALITY - RGB SOURCE`

Item	Description
RGB Intent	Specifies the characteristic applied when converting RGB image data to CMYK data. If **Vivid** is selected, a vivid output is produced. If **Photographic** is selected, a brighter output is produced. Choices: Vivid, Photographic Default: Photographic Configuration Menu Equivalent: `CAMERA DIRECT - IMAGE QUALITY - RGB INTENT`
RGB Gray Treatment	Specifies how black and grays are reproduced in RGB image data. If **Composite Black** is selected, black is reproduced using the CMYK colors. If **Black And Gray** is selected, black and gray are reproduced using black only. If **Black Only** is selected, black is reproduced using only black. Choices: Composite Black, Black And Gray, Black Only Default: Composite Black Configuration Menu Equivalent: `CAMERA DIRECT - IMAGE QUALITY - RGB GRAY`
Halftone	Specifies how halftones are reproduced. If **Line Art** is selected, halftones are reproduced with high precision. If **Detail** is selected, halftones are reproduced with detail. If **Smooth** is selected, halftones are reproduced with smoothness. Choices: Line Art, Detail, Smooth Default: Detail Configuration Menu Equivalent: `CAMERA DIRECT - IMAGE QUALITY - HALFTONE`
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Download Font/Form

PS Font



The printer must have the optional hard disk to use the PS Font parameters described below.

The **Print - Download Font/Form - PS Font** window allows you to configure the following items:

Item		Description
Download PS Font	Text box	Specifies the file name for the PostScript font to be downloaded.
	Browse button	Displays a dialog box for browsing to the PostScript font file.
	Submit button	Sends the specified PostScript font file to the printer.
Delete PS Font	Check box	Select the check box of the font to be deleted, and then click **Delete** to delete the selected font from the printer.
	Number	Displays the control number of the font.
	Font Name	Displays the name of the fonts.
Delete button		Deletes the PostScript font file(s) whose check boxes the left end are checked.
Logout button		Logs out of Administrator Mode and returns to User Mode.

Form Overlay



The **Print - Download Font/Form - Form Overlay** window allows you to configure the following items:

Item		Description
Download Form Overlay	Text box	Specifies the file name for the form overlay to be downloaded.
	Browse button	Displays a dialog box for browsing to the form overlay file.
	Submit button	Sends the specified form overlay file to the printer.
Delete Form Overlay	Check box	Select the check box of the form overlay file to be deleted, and then click **Delete** to delete the selected form overlay from the printer.
	Number	Displays the control number of the overlay.
	File Name	Displays the name of the overlays.
Delete button		Deletes the PostScript font file(s) whose check boxes the left end are checked.
Logout button		Logs out of Administrator Mode and returns to User Mode.

Color Profile



The **Print - Download Font/Form - Color Profile** window allows you to configure the following items:

Item		Description
Download Color Profile	Text box	Specifies the file name for the color profile to be downloaded.
	Browse button	Displays a dialog box for browsing to the color profile file.
	Submit button	Sends the specified color profile file to the printer.
Delete Color Profile	Check box	Select the check box of the color profile file to be deleted, and then click **Delete** to delete the selected color profile from the printer.
	Number	Displays the control number of the color profile.
	File Name	Displays the name of the color profile.
	Class	Displays the type of color profile.
	Color Space	Displays the color space for the color profile.
	Available	Indicates whether or not the color profile can be used.
Delete button		Deletes the PostScript font file(s) whose check boxes the left end are checked.

Item	Description
Logout button	Logs out of Administrator Mode and returns to User Mode.

When specifying a file name for the form overlay and the color profile downloaded to the printer, make sure that the name complies with the 8.3 format (MS-DOS file name format).
If a long file name has been specified, the data is downloaded; however, it cannot be correctly referenced from the printer driver or Download Manager.

Network

The Network page allows you to configure network settings. For more information on these protocols, see chapter 6, “Network Printing.”



TCP/IP

TCP/IP (shown above)

The **Network - TCP/IP - TCP/IP** window allows you to configure the following items. For more information on these TCP/IP, see chapter 6, “Network Printing.”

Item	Description
TCP/IP	Sets whether or not to use TCP/IP. Choices: Enable, Disable Default: Enable Configuration Menu Equivalent: `INTERFACE MENU - ETHERNET - TCP/IP - ENABLE`

Item	Description
Speed	Specifies the operating mode and speed for Ethernet. Choices: Auto, 10Base-T(Half), 10Base-T(Full), 100Base-TX(Half), 100Base-TX(Full), 1000Base-T(Full) Default: Auto Configuration Menu Equivalent: `INTERFACE MENU - ETHERNET - SPEED/DUPLEX`
Auto IP	Specifies the automatic assigning method for the printer IP address. Choices: DHCP/BOOTP Default: Checked Configuration Menu Equivalent: `INTERFACE MENU - ETHERNET - TCP/IP - DHCP/BOOTP`
IP Address*	Sets the printer's IP address. Range: 0–255 for each *xxx* triplet Default: 0.0.0.0 *If the specified IP address is outside of the allowable range, the value is not changed, even after the **Apply** button is clicked. The setting returns to the previous value.* Configuration Menu Equivalent: `INTERFACE MENU - ETHERNET - TCP/IP - IP ADDRESS`
Subnet Mask*	Sets the printer's subnet mask address. Range: 0–255 for each *xxx* triplet Default: 255.255.0.0 *If the specified subnet mask address is outside of the allowable range, the value is not changed, even after the **Apply** button is clicked. The setting returns to the previous value.* Configuration Menu Equivalent: `INTERFACE MENU - ETHERNET - TCP/IP - SUBNET MASK`

Item	Description
Default Gateway*	If a router is used on the network, sets the router's address. Range: 0–255 for each *xxx* triplet Default: 0.0.0.0 *If the specified router address is outside of the allowable range, the value is not changed, even after the **Apply** button is clicked. The setting returns to the previous value.* Configuration Menu Equivalent: `INTERFACE MENU - ETHERNET - TCP/IP - DEFAULT GATEWAY`
RAW Port Number	Identifies the number of the printer's RAW port. Choices: 1 - 65535 Default: 9100
Host Name	Specifies the host name. Default: magicolor5450
Domain Name	Specifies the domain name. Default: [Blank]
DNS Server	Specifies the DNS server. Up to three can be registered. Default: 0.0.0.0
Dynamic DNS	Select whether or not Dynamic DNS is used. Choices: Enable, Disable Default: Disable
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Log out button	Logs out of Administrator Mode and returns to User Mode.
* Always enter these addresses without leading zeros. For example, 131.011.010.001 should be entered as 131.11.10.1.	



The **Network - TCP/IP - IP Address Filtering** page allows you to specify the IP address and limitations for accessing the printer.

The settings described below are not applied to the DNS server and DHCP server.

*If the range of permitted IP addresses in **Access Permission Address** overlaps the range of refused IP address in **Access Refuse Address**, the refuse setting of **Access Refuse Address** is given priority.*

Item	Description
Access Permission Address	If **Enable** is selected, the range of IP addresses permitted access to the printer can be specified. A maximum of five ranges of permitted IP addresses can be specified. In addition, access from an IP address out of the specified range is prohibited. If **Disable** is selected, the permitted access setting is disabled. Choices: Enable, Disable Default: Disable
Range of IP address permitted access	Specify the range of IP addresses permitted access to the printer. Type the IP address at the beginning of the range into the box on the left, and the IP address at the end of the range into the box on the right. Range: 0-255 for each xxx triplet Default: 0.0.0.0 *To specify a single IP address, type the same IP address into both the box for the starting IP address and for the ending IP address, or type "0.0.0.0" into the box for either the starting IP address or the ending IP address.* *If the starting IP address is larger than the ending IP address, the setting is not applied.*
Access Refuse Address	If **Enable** is selected, the range of IP addresses refused access to the printer can be specified. A maximum of five ranges of refused IP addresses can be specified. If **Disable** is selected, the refused access setting is disabled. Choices: Enable, Disable Default: Disable

Item	Description
Range of IP address refused access	Specify the range of IP addresses refused access to the printer. Type the IP address at the beginning of the range into the box on the left, and the IP address at the end of the range into the box on the right. Range: 0-255 for each xxx triplet Default: 0.0.0.0 *To specify a single IP address, type the same IP address into both the box for the starting IP address and for the ending IP address, or type "0.0.0.0" into the box for either the starting IP address or the ending IP address.* *If the starting IP address is larger than the ending IP address, the setting is not applied.*
Apply button	Applies the configuration settings in this page.
Clear button	Resets all configuration settings to previous values.
Log out button	Logs out of Administrator Mode and returns to User Mode.

Bonjour



The **Network - Bonjour** page allows you to configure the following items.

Item	Description
Bonjour	Select whether to enable or disable the Bonjour function. Choices: Enable, Disable Default: Enable
Bonjour Name	Specify the Bonjour name for the printer. Range: Up to 63 characters Default: KONICA MINOLTA magicolor 5450(xx:xx:xx) *"xx:xx:xx" refers to the last six digits of the MAC address (in hexadecimal).*
Apply button	Applies the configuration settings in this page.
Clear button	Resets all configuration settings to previous values.
Log out button	Logs out of Administrator Mode and returns to User Mode.

NetWare

NetWare



The **Network - NetWare - NetWare** window allows you to configure the following items:

Item		Description
NetWare	NetWare Print	Enables or Disables the NetWare print option. Choices: Enable, Disable Default: Enable Configuration Menu Equivalent: `INTERFACE MENU - ETHERNET - NETWARE - ENABLE`
	Frame Type	Specifies the Frame Type. Choices: Auto, Ethernet802.2, Ethernet 802.3, Ethernet II, Ethernet SNAP Default: Auto
	Mode	Specifies the NetWare Configuration mode. Choices: Disable, PServer, NPrinter/ RPrinter Default: PServer
PServer	Print Server Name	Sets the Print Server Name for the printer. Range: Up to 47 characters Default: [Blank]
	Print Server Password	Sets the Print Server password. Range: Up to 31 characters Default: [Blank]
	Retype Password	Verifies the new password typed in the Print Server Password text box. Range: Up to 31 characters Default: [Blank]
	Print Queue Scan Rate	Sets the number of the queue scan interval. Range: 1 - 65535 (Seconds) Default: 1
	Bindery/NDS	Specifies the bindery options. Choices: NDS, Bindery/NDS, Bindery Default: NDS

Item		Description
	Preferred File Server	Sets the Preferred File Server for the printer. Range: Up to 47 characters Default: [Blank]
	Preferred NDS Context Name	Sets the Preferred NDS Context for the printer. Range: Up to 191 characters Default: [Blank]
	Preferred NDS Tree Name	Sets the Preferred NDS Tree for the printer. Range: Up to 63 characters Default: [Blank]
NPrinter/ RPrinter	Printer Name	Sets the printer's name. Range: Up to 47 characters Default: [Blank]
	Printer Number	Sets the Printer Number. Range: 0 - 255 Default: 255
Apply button		Applies the configuration settings for this window.
Clear button		Resets all configuration settings to previous values.
Logout button		Logs out of Administrator Mode and returns to User Mode.

NetWare Status



The **Network - NetWare - NetWare Status** window allows you to configure the following items:

Item	Description
File Server	Identifies current NetWare File Server.
Queue Name	Identifies current NetWare queue name.
Queue Status	Identifies current NetWare status.
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

IPP



The **Network - IPP** window allows you to configure the following items. For details on IPP, refer to chapter 6, “Network Printing.” In order to apply the settings, the printer must be turned off, then on again after the setting is specified.

Item	Description
IPP Print	Sets whether or not to use IPP. Choices: Enable, Disable Default: Enable
Accept IPP Job	Sets whether or not to accept IPP Job. Choices: Enable, Disable Default: Enable
Printer Name	Sets the printer’s name. Range: Up to 127 characters Default: [Blank]

Item	Description
Printer Location	Sets the printer's location. Range: Up to 127 characters Default: [Blank]
Printer Information	Specifies the printer information. Range: Up to 127 characters Default: [Blank]
Printer URI	Specifies the printer's Uniform Resource Identifier (URI), authentication, and security. Range: Non-configurable Defaults: ■ http://<IP_address>/ipp RequestingUserName None ■ http://<IP_address>:80/ipp RequestingUserName None ■ ipp://<IP_address>:80/ipp RequestingUserName None ■ http://<IP_address>:631/ipp RequestingUserName None ■ ipp://<IP_address>/ipp RequestingUserName None ■ ipp://<IP_address>:631/ipp RequestingUserName None ■ http://<IP_address>:443/ipp RequestingUserName None ■ ipp://<IP_address>:443/ipp RequestingUserName None *"http://<IP_address>:443/ipp" and "ipp://<IP_address>:443/ipp" appear only if the SSL/TLS settings are enabled.*

Item		Description
Operational Support	Print Job	If this check box is selected, Print Job is enabled. Default: Checked
	Validate Job	If this check box is selected, Validate Job is enabled. Default: Checked
	Cancel Job	If this check box is selected, Cancel Job is enabled. Default: Checked
	Get Job Attributes	If this check box is selected, Get Job Attribute is enabled. Default: Checked
	Get Jobs	If this check box is selected, Cancel Job is enabled. Default: Checked
	Get Print Attributes	If this check box is selected, Get Printer Attribute is enabled. Default: Checked
Apply button		Applies the configuration settings for this window.
Clear button		Resets all configuration settings to previous values.
Logout button		Logs out of Administrator Mode and returns to User Mode.

FTP

Server



The **Network - FTP - Server** window allows you to configure the following items:

Item	Description
FTP Server	Enables or Disables the FTP server. Choices: Enable, Disable Default: Enable
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

SNMP



The **Network - SNMP** window allows you to configure the following items:

Item	Description
SNMP	If Enable is selected, SNMP is enabled. Choices: Enable, Disable Default: Enable
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

SMB

Print



The **Network - SMB - Print** window allows you to configure the following items:

Item	Description
SMB Print	If Enable is selected, SMB Print is enabled. Choices: Enable, Disable Default: Enable
NetBIOS Name	Sets NetBIOS Name for the printer. Range: Up to 15 characters Default: magicolor5450
Print Service Name	Sets Print Server Name. Range: Up to 12 characters Default: MC5450
Work Group	Sets Work Group name. Range: Up to 15 characters Default: WORKGROUP
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

AppleTalk



The **Network - AppleTalk** window allows you to configure the following items:

Item	Description
AppleTalk	If Enable is selected, AppleTalk is enabled. Choices: Enable, Disable Default: Enable Configuration Menu Equivalent: `INTERFACE MENU - ETHERNET - APPLE TALK`
Printer Name	Sets the printer name. Range: Up to 31 characters Default: magicolor5450
Zone Name	Sets the Zone Name. Range: Up to 31 characters Default: *
Current Zone Name	Identifies the current zone name.
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Email

Send Email



The **Network - Email - Send Email** window allows you to configure the following items:

Item	Description
Send	If Enable is selected, sending Email is enabled. Choices: Enable, Disable Default: Enable
SMTP Server Address	Specifies the address of the mail transmission server. Range: Up to 255 characters Default: 0.0.0.0
Port Number	Specifies the port number of the mail transmission server. Range: 1 - 65535 Default: 25
Connection Timeout	Specifies the amount of time until the connection times out when sending e-mail. Range: 30 - 300 (seconds) Default: 60

Item	Description
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

SSL/TLS Information



The **Network - SSL/TLS - SSL/TLS Information** page allows you to specify SSL/TLS settings.

*As a default, SSL/TLS is not installed. Click **Setting** to create a certificate and specify the SSL settings.*

Item	Description
Setting button	Displays the **SSL/TSL Setting** page.
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

SSL/TLS Setting



The **Network - SSL/TLS - SSL/TLS Setting** page allows you to select the following SSL/TLS settings that appear.

Item	Description
Create a self-signed Certificate	Creates a self-signed certificate.
Request a certificate	Creates data for requesting that a certificate be issued from a certificate authority.
Install a certificate	Installs the certificate issued by the certificate authority.
Set a Encryption Strength	Specifies the encryption level. In addition, SSL/TLS can be disabled. *If no certificate is installed, this item does not appear.*
Remove a certificate	Removes the certificate. *If no certificate is installed, this item does not appear.*
Mode Using SSL/TLS	Specifies the SSL transmission mode. *If no certificate is installed, this item does not appear.*

Item	Description
Next button	Click to display the selected page.
Apply button	Applies the configuration settings for this window.
Cancel button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Self-signed Certificate Setting



The **Network - SSL/TLS - Self-signed Certificate Setting** page allows you to create a certificate and specify SSL settings.

Item	Description
Common Name	Identifies the Common Name for the printer, to be used in creation of an SSL Certificate. It is comprised of "Printer Host Name.DNS Server". If DNS Server is un-available, only the host name is used as Common Name. *This text is read-only.*

Item	Description
Organization	Specify the name of the group or organization. Range: Up to 63 characters Default: [Blank]
Organization Unit	Specify the name of the post. Range: Up to 63 characters Default: [Blank]
Locality	Specify the name of the municipality. Range: Up to 127 characters Default: [Blank]
State/Province	Specify the name of the state or province. Range: Up to 127 characters Default: [Blank]
Country	Specify the name of the country as a country code regulated by ISO03166. Range Up to 2 characters Default: [Blank]
Email Address	Specify the e-mail address. Range: Up to 127 characters Default: [Blank]
Validity Start Date	Displays the current time.
Validity Period	Specify the period of validity. Range: 1 - 3650 (day) Default: [Blank]
Encryption Strength	Specify the encryption level. Choices: -3DES_168bits, RC4_128bits, DES_56bits or RC4_40bits -RC4_128bits, DES_56bits or RC4_40bits -DES_56bits or RC4_40bits Default: 3DES_168bits,RC4_128bits, DES_56bits or RC4_40bits
Create button	Creates the self-signed certificate. *A few minutes are needed in order to create the certificate.*
Apply button	Applies the configuration settings for this window.
Clear button	Resets all configuration settings to previous values.

Item	Description
Logout button	Logs out of Administrator Mode and returns to User Mode.

Request a certificate



The **Network - SSL/TLS - Request a Certificate** page allows you to configure the following items:

Item	Description
Common Name	Identifies the Common Name for the printer, to be used in creation of an SSL Certificate. It is comprised of "Printer Host Name.DNS Server". If DNS Server is un-available, only the host name is used as Common Name. *This text is read-only.*
Organization	Specifies the name of the group or organization. Range: Up to 63 characters Default: [Blank]
Organization Unit	Specifies the name of the post. Range: Up to 63 characters Default: [Blank]

Item	Description
Locality	Specifies the name of the municipality. Range: Up to 127 characters Default: [Blank]
State/Province	Specifies the name of the state or province. Range: Up to 127 characters Default: [Blank]
Country	Specify the name of the country as a country code regulated by ISO03166. Range: Up to 2 characters Default: [Blank]
Email Address	Specify the e-mail address. Range: Up to 127 characters Default: [Blank]
Next button	Click to create data for requesting that a certificate be issued.
Back button	Click to return to the **Network - SSL/TLS - SSL/ TLS Setting** page.
Cancel button	Resets all configuration settings to previous values.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Certificate Request



The **Network - SSL/TLS - Certificate Request** page displays the data that will be submitted to the certificate authority to request that a certificate be issued.

Item	Description
Certificate Request	Displays the data that should be submitted to the certificate signing authority. This is called CSR (Certificate Signing Request). This data is to be submitted to the certificate signing authority by the user.
Save button	Click to save the data for requesting the certificate with the specified name.
OK button	Click to return to the **Network - SSL/TLS - SSL/TLS Setting** page.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Install a Certificate



The **Network - SSL/TLS - Install a Certificate** page allows you to install the certificate issued by the certificate authority.

Item	Description
Install a Certificate	Signed CSR (Certificate Signing Request) should be pasted to this text area.
Next button	Click to display the **Network - SSL/TLS - Encryption Strength Setting** page.
Back button	Click to return to the **Network - SSL/TLS - SSL/TLS Setting** page.
Cancel button	Click to cancel the entered data and return to the **Network - SSL/TLS - SSL/TLS Information** page.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Encryption Strength Setting



The **Network - SSL/TLS - Encryption Strength Setting** page allows you to specify the encryption level.

Item	Description
Encryption Strength	Specify the encryption level. Choices: ■ 3DES_168bits, RC4_128bits, DES_56bits or RC4_40bits ■ RC4_128bits, DES_56bits or RC4_40bits ■ DES_56bits or RC4_40bits Default: 3DES_168bits,RC4_128bits, DES_56bits or RC4_40bits
Create button	Click to specify the encryption level. If the **Network - SSL/TLS - Install a Certificate** page was previously displayed, the certificate is installed.
Back button	Click to return to the **Network - SSL/TLS - SSL/TLS Setting** page.
Cancel button	Returns to the previous screen.

Item	Description
Logout button	Logs out of Administrator Mode and returns to User Mode.

Remove a Certificate

The **Network - SSL/TLS - Remove a Certificate** page allows you to delete the installed certificate.

Item	Description
OK button	Click to display a confirmation message. Click **OK** in the confirmation message to delete the certificate.
Back button	Click to return to the **Network - SSL/TLS - SSL/TLS Setting** page.
Cancel button	Click to return to the **Network - SSL/TLS - SSL/TLS Information** page.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Mode using SSL/TLS

The **Network - SSL/TLS - Mode using SSL/TLS** page allows the SSL transmission mode to be specified.

Item	Description
Mode using SSL/TLS	Selects the SSL transmission mode. Choice: Disable, Enable Default: Disable
Apply button	Click to apply the setting specified beside “Mode using SSL/TLS”.
Back button	Click to return to the **Network - SSL/TLS - SSL/TLS Setting** page.
Cancel button	Click to return to the **Network - SSL/TLS - SSL/TLS Setting** page.
Logout button	Logs out of Administrator Mode and returns to User Mode.

Log Accounting Page

If the optional hard disk drive is installed on the printer, printer account information can be specified from the **Log Accounting** page.



Job (shown above)

The **Log Accounting** - **Job** page allows you to save the job information for the printer as a file.

Item		Description
Number of the record to retrieve as a file	By Number	Select the number of jobs to be retrieved and saved as a file. Choices: 10, 50, 100, 250, 500, All Default: 10
Get button		Click to display a dialog box for selecting the location where the job information file is to be saved.
Log out button		Logs out of Administrator Mode and returns to User Mode.

Index

A

Active job list, PageScope Web Connection
Print job status 147
Administrator mode, PageScope Web Connection 134
Alert mail, PageScope Web Connection 177
AppleTalk 11
AppleTalk, PageScope Web Connection 222

B

Bonjour 113, 211
Bonjour, PageScope Web Connection 211
BOOTP 101, 113

C

Camera Direct Print, PageScope Web Connection 157, 198
Certificate request, PageScope Web Connection 230
Chooser 48
Clear settings, PageScope Web Connection 175
Color profile, PageScope Web Connection 162, 203
Configuration
Network settings 98, 205
Printer, via PageScope Web Connection 165
Configuration, PageScope Web Connection 205
AppleTalk 222
Camera Direct Print 157, 198
Certificate request 230
Email 223

Encryption strength setting 232
FTP 219
Install a certificate 231
Mode using SSL/TLS 234
NetWare 212
Remove a certificate 233
Request a certificate 228
Self-signed certificate setting 226
SMB 221
SNMP 220
SSL/TLS information 224
SSL/TLS setting 225
TCP/IP 205
Consumables, PageScope Web Connection 144
Counter, PageScope Web Connection 145
Crown Print Monitor+ 94, 122

D

Date/Time, PageScope Web Connection 165
DDNS 114
Desktop printer utility 51
Details, PageScope Web Connection 138
Done job list 149
Paper source 138
Device information, PageScope Web Connection 137, 169
Device status, PageScope Web connection 136
DHCP 101, 107, 114
Direct print, PageScope Web Connection 164
Done job list, PageScope Web Connection 148
Download Manager Utility 94

E

Email, PageScope Web Connection 223
Encryption strength setting, PageScope Web Connection 232
Ethernet interface 107
Ethernet menu 98
Accessing 99
AppleTalk 102
DHCP/BOOTP 101
Gateway 101
IP address 100
Speed/Duplex 102
Subnet mask 100
Using options 100

F

Form overlay, PageScope Web Connection 161, 202
FTP PageScope Web Connection 219

G

Gateway 101, 107
Manual setting 109
General settings, PageScope Web Connection 150, 181

H

Hard disk, PageScope Web Connection 141
Host table 130
HTTP 114

I

Install a certificate, PageScope Web Connection 231
Installing
Certificate 231
Crown print monitor+ 94
Download manager utility 94
Management information base 94
PageScope Network Setup 94
Printer driver 3, 79
Printer Management Utilities 94
Status monitor 94
Interface, PageScope Web Connection 142
IP address 100, 107
Manual setting 109
IP Address Filtering 208

IP Address Filtering, PageScope Web Connection 208
IPP 114
Printing via 117
IPP, PageScope Web Connection 216
IPX/SPX 115

J

Job 235
Job, PageScope Web Connection 147, 235
Active job list 147
Done job list 148

L

Linux
Adding the printer 80
Checking print jobs 91
PPD file, installing 79
Print settings 87
Printer driver settings 82
System requirements 78
Troubleshooting 92
Local interface, PageScope Web Connection 180
Log Accounting, PageScope Web Connection 235
Job 235
LPD/LPR 115

M

Mac OS 9
Chooser 48
Desktop printer utility 51
Options 48
Page setup settings 54
Printer driver, installing 47
System requirements 46
Troubleshooting 75
Mac OS X
Options 20
Page setup settings 22
Print settings 26
Printer driver, installing 3
Printer setup utility 8
Printer setup utility settings 8
System requirements 2
Troubleshooting 43
Management information base 94
Mode using SSL/TLS, PageScope Web Connection 234

N

NetBEUI 115
NetWare 102
NetWare, PageScope Web Connection 212
Network connection 106
Address setting 109
Ethernet interface 107
Making connections 107
Theory 106
Using DHCP 107
Network menu
Overview 98
Network printing 113
Network setting 98
Network, PageScope Web Connection
Bonjour 211
Configuration 205
IP Address Filtering 208

O

Online assistance, PageScope Web Connection 146, 173
Output tray, PageScope Web Connection 140

P

Page setup settings 22, 54
Custom paper size options 24, 55
Page attributes options 23, 54
Summary 25
PageScope Network Setup 94
PageScope Web Connection 128
Active job 147
Administrator mode 134

Alert mail 177
AppleTalk 222
Camera Direct Print 157, 198
Certificate request 230
Clear settings 175
Color profile 162, 203
Consumables 144
Counter 145
Current status 134
Date/Time 165
Details 138
Device information 137, 169
Direct print 164
Display language 128
Done job list 148
Email 223
Encryption strength setting 232
Form overlay 161, 202
FTP 219
General settings 150, 181
Hard disk 141
Install a certificate 231
Interface information 142
Job 147
Local interface 180
Mode using SSL/TLS 234
Navigation 133
NetWare 212
Online assistance 146, 147
Output tray 140
Paper source 138
Paper source settings 152, 184
PCL font 159
PCL settings 153, 188
Print quality settings 155, 191
Printer configuration 165
PS font 160, 201
PS settings 154, 190
Remove a certificate 233
Report types 163
Request a certificate 228
Requirements 128
Reset printer 176
ROM version 172
Self-signed certificate setting 226
SMB 221
SNMP 220
SSL/TLS information 224
SSL/TLS setting 225
TCP/IP 205
User mode 134
Viewing printer status 135
Window 133
Paper source settings, PageScope Web Connection 152, 184
Paper source, PageScope Web Connection 138
Password, PageScope Web Connection 167
PCL font, PageScope Web Connection 159
PCL settings, PageScope Web Connection 153, 188
Port 9100 116
Print jobs
Checking 74, 91
Print quality settings, PageScope Web Connection 155, 191
Print, PageScope Web Connection 150, 180
Color profile 162, 203
Direct print 164
Form overlay 161, 202
General settings 150, 181
Local interface 180
Paper source settings 152, 184
PCL font 159
PCL settings 153, 188
Print quality settings 155, 191
PS font 160, 201
PS settings 154, 190
Report types 163
Printer name 130
Printer Setup Utility 8
AppleTalk 11
IP printing setting 14
Network connection 11
Specifying port 9100 17
USB connection 8
Printer status 135
Protocols, network
BOOTP 113
DHCP 114
HTTP 114

IPP 114
IPX/SPX 115
LPD/LPR 115
NetBEUI 115
SLP 115
SMB 116
SMTP 116
SNMP 116
PS font, PageScope Web Connection 160, 201
PS settings, PageScope Web Connection 154, 190

R

Remove a certificate, PageScope Web Connection 233
Rendezvous 211
Report types, PageScope Web Connection 163
Request a certificate, PageScope Web Connection 228
Reset printer, PageScope Web Connection 176
ROM version, PageScope Web Connection 172

S

Self-signed certificate setting, PageScope Web Connection 226
SLP 115
SMB 116
SMB, PageScope Web Connection 221
SMTP 116
SNMP 116
SNMP, PageScope Web Connection 220
SSL/TLS information, PageScope Web Connection 224
SSL/TLS setting, PageScope Web Connection 225
Staus monitor 94
Subnet mask 100, 107
Manual setting 109
Summary, PageScope Web Connection
Device status 136
System requirements
Linux 78
Mac OS 9 46
Mac OS X 2
System, PageScope Web Connection 135, 165
Alert mail 177
Clear settings 175
Counter 145
Date/Time 165
Details 138
Device information 137, 169
Hard disk 141
Interface information 142
Online assistance 146, 173
Output tray 140
Password 167
Reset printer 176
ROM version 172
Summary 136

T

TCP/IP, PageScope Web Connection 205
Troubleshooting
Linux 92
Mac OS 9 75
Mac OS X 43

U

User mode, PageScope Web Connection 134

W

Web page, printer 130
Browser 130
Printer name 130